



# Integrator's Reference Manual for the VSX Series

Version 8.6 Addendum for SCCP

December 2006 Edition  
3725-24334-001/A  
VSX Version 8.6



---

## **Trademark Information**

Polycom®, the Polycom logo design, SoundStation®, SoundStation VTX 1000®, and Vortex® are registered trademarks of Polycom, Inc., and Conference Composer™, Global Management System™, ImageShare™, MGC™, People+Content™, Polycom *InstantDesigner*™, Polycom PathNavigator™, PowerCam™, Siren™, StereoSurround™, Visual Concert™, VSX™, and VTX™ are trademarks of Polycom, Inc. in the United States and various other countries. VISCA is a trademark of Sony Corporation. All other trademarks are the property of their respective owners.

## **Patent Information**

The accompanying product is protected by one or more U.S. and foreign patents and/or pending patent applications held by Polycom, Inc.

© 2006 Polycom, Inc. All rights reserved.

Polycom Inc.  
4750 Willow Road  
Pleasanton, CA 94588-2708  
USA

No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of Polycom, Inc. Under the law, reproducing includes translating into another language or format.

As between the parties, Polycom, Inc. retains title to, and ownership of, all proprietary rights with respect to the software contained within its products. The software is protected by United States copyright laws and international treaty provision. Therefore, you must treat the software like any other copyrighted material (e.g. a book or sound recording).

Every effort has been made to ensure that the information in this manual is accurate. Polycom, Inc. is not responsible for printing or clerical errors. Information in this document is subject to change without notice.

---

# System Commands

This document describes the API commands that have been modified for VSX Series Version 8.6 for SCCP.

For information about using the VSX Series API commands and a listing of the other API commands, refer to the [Integrator's Reference Manual for the VSX Series, Version 8.5](#).

## About the API Commands

### Syntax Conventions

The following conventions are used for the API command descriptions in this chapter. All of the commands are case sensitive.

Convention	Meaning
<param1 param2 param3>	Multiple valid parameters are enclosed in angle brackets and separated by the pipe (" ") character. Example: <code>allowdialing &lt;yes no get&gt;</code> shows that the <code>allowdialing</code> command must be followed by one of the parameters listed.
[param] ["param"]	Optional parameters are enclosed in square brackets. Quotation marks indicate strings to be supplied by the user. Example: <code>ping "xxx.xxx.xxx.xxx" ["count"]</code> shows that you can supply a value for <code>count</code> , or omit it and let the default value apply. You do not need to enclose a value in quotes unless it contains a space.
{a..z}	A range of possible alphanumeric values is enclosed in braces. Example: <code>abk letter {a..z}</code> shows that the <code>abk</code> command can be used to return address book entries that begin with an alphanumeric character in the range specified. Example: <code>camera near {1..4}</code> shows that the <code>camera</code> command can be used to select camera 1, 2, 3, or 4 at the near site.
"x"	Quotation marks indicate strings to be supplied by the user. You do not need to enclose the value in quotes unless it contains a space.

Although the API command parser may accept the minimum number of characters in a command which makes it unique, you should always use the full command string.

## Availability of Commands

The availability of API commands depends on the type of system and optional equipment installed or connected. If a setting is not configured on the system, issuing a command for that particular setting returns the feedback that the command is not supported for this configuration.

*Deprecated* commands are included for backward compatibility only and are not recommended for use with this version. Suitable replacements are noted for each deprecated command.

## callinfo

Lets you get the connection ID for an active call. This command is only available when the system is in a call.

### Syntax

```
callinfo all
```

### Feedback example

This example shows the response for a call with the connection ID "3".

```
callinfo begin
callinfo:3:John-7000e:136102:connected:muted:outgoing:videocall
callinfo end
```

## conference

Adds another site to an existing call. Note that a conference must be initiated by a site in an active call. Other sites cannot join an active call to create a conference.

Note that this command must be used twice for each site added: once to initiate the conference, and again to complete the conference.

### Syntax

```
conference manual "connectionID" "newNumber"
```

Parameter	Description
"connectionID"	Identifier found by using the <code>callinfo</code> command or displayed in the most recent system response. For example, the Connection ID is 2 in the following system response: <pre>active: call[2] speed[832]</pre> <ul style="list-style-type: none"> <li>In the first instance of the conference command, use the Connection ID of the Active Call.</li> <li>In the second instance of the conference command, use the Connection ID of the new call.</li> </ul>
"newNumber"	SCCP extension of the site you want to add.

### Feedback Examples

The VSX system returns the following responses over telnet port 24:

- `conference manual connID[1] Success`
- `conference manual connID[n] Failed`

## connection hold

Places the call on hold or resumes a call that is on hold.

### Syntax

```
connection hold "connectionID" "on" | "off"
```

Parameter	Description
"connectionID"	Connection ID of the active call.
"on"   "off"	"on" puts the call on hold. "off" resumes a call that is on hold.

### Feedback Examples

The VSX system returns the following responses over telnet port 24:

- connection hold "connectionID" on successful
- connection hold "connectionID" off successful
- connection hold "connectionID" on failed
- connection hold "connectionID" off failed

## dial

Dials video or audio calls either manually or from the directory.

### Syntax

```
dial manual "dialstr1"
```

Parameter	Description
"dialstr1"	Valid ISDN or IP directory number.
manual	Dials a video call number dialstr1 at speed of type h323 or h320. Requires the parameters "speed" and "dialstr1".

## forward

Sends calls to another site. This setting applies to future calls. An active call cannot be forwarded.

### Syntax

```
forward unconditional address "extension" on
forward unconditional off
```

Parameter	Description
"extension"	Specifies the SCCP extension to which calls will be forwarded.

### Feedback Example

- forward unconditional address 132182 on  
...
- forward unconditional off

## setPrimaryTftpAddr

Sets the Primary TFTP server IP address.

### Syntax

```
setPrimaryTftpAddr "xxx.xxx.xxx.xxx"
```

Parameter	Description
"xxx.xxx.xxx.xxx"	IP address of the Primary TFTP server.

### Feedback Examples

```
Primary TFTP IP address successfully changed [1]
Restart system for changes to take effect. Restart now?<y,n>
```

## setSecondaryTftpAddr

Sets the Secondary TFTP server IP address.

### Syntax

```
setSecondaryTftpAddr "xxx.xxx.xxx.xxx"
```

Parameter	Description
"xxx.xxx.xxx.xxx"	IP address of the Secondary TFTP server.

### Feedback Examples

```
Secondary TFTP IP address successfully changed [1]  
Restart system for changes to take effect. Restart now?<y,n>
```

## setTertiaryTftpAddr

Sets the Tertiary TFTP server IP address.

### Syntax

```
setTertiaryTftpAddr "xxx.xxx.xxx.xxx"
```

Parameter	Description
"xxx.xxx.xxx.xxx"	IP address of the Tertiary TFTP server.

### Feedback Examples

```
Tertiary TFTP IP address successfully changed [1]  
Restart system for changes to take effect. Restart now?<y,n>
```



## transfer

Transfers the active call to another site. Note that only the active call can be transferred. This command must be used twice: once to initiate the transfer and again to complete the transfer.

### Syntax

```
transfer manual "connectionID" "destinationAddress"
```

Parameter	Description
"connectionID"	Identifier found by using the <code>callinfo</code> command or displayed in the most recent system response. For example, the Connection ID is 2 in the following system response:  active: call[2] speed[832]
"connectionID"	Connection ID of the new call.
"destinationAddress"	The SCCP extension of the destination site.

### Feedback Example

The VSX system returns responses over telnet port 24. The following example transfers a call to extension 132182.

```
active: call[2] speed[832]
transfer manual 2 13282
active: call[3] speed[832]
transfer manual 3 13282
transfer manual connID[3] Success
```

If the transfer was unsuccessful, the system returns the following message instead:

```
transfer manual connID[3] Failed
```

