



SOLUTION GUIDE

| August 2018 | 3725-84753-002A

---

# Integrating Polycom Trio<sup>TM</sup> Systems with Zoom Rooms

A decorative graphic at the bottom of the page features several overlapping, curved bands. One prominent band is a vibrant red, while others are a light blue-grey. The bands curve from the bottom left towards the right, creating a sense of motion and depth.

Copyright© 2018, Polycom, Inc. All rights reserved. No part of this document may be reproduced, translated into another language or format, or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of Polycom, Inc.

6001 America Center Drive  
San Jose, CA 95002  
USA

**Trademarks** Polycom®, the Polycom logo and the names and marks associated with Polycom products are trademarks and/or service marks of Polycom, Inc. and are registered and/or common law marks in the United States and various other countries.



All other trademarks are property of their respective owners. No portion hereof may be reproduced or transmitted in any form or by any means, for any purpose other than the recipient's personal use, without the express written permission of Polycom.

**End User License Agreement** By installing, copying, or otherwise using this product, you acknowledge that you have read, understand and agree to be bound by the terms and conditions of the End User License Agreement for this product. The EULA for this product is available on the Polycom Support page for the product.

**Patent Information** The accompanying product may be protected by one or more U.S. and foreign patents and/or pending patent applications held by Polycom, Inc.

**Open Source Software Used in this Product** This product may contain open source software. You may receive the open source software from Polycom up to three (3) years after the distribution date of the applicable product or software at a charge not greater than the cost to Polycom of shipping or distributing the software to you. To receive software information, as well as the open source software code used in this product, contact Polycom by email at <mailto:OpenSourceVideo@polycom.com> (for video products) or <mailto:OpenSourceVoice@polycom.com> (for voice products).

**Disclaimer** While Polycom uses reasonable efforts to include accurate and up-to-date information in this document, Polycom makes no warranties or representations as to its accuracy. Polycom assumes no liability or responsibility for any typographical or other errors or omissions in the content of this document.

**Limitation of Liability** Polycom and/or its respective suppliers make no representations about the suitability of the information contained in this document for any purpose. Information is provided "as is" without warranty of any kind and is subject to change without notice. The entire risk arising out of its use remains with the recipient. In no event shall Polycom and/or its respective suppliers be liable for any direct, consequential, incidental, special, punitive or other damages whatsoever (including without limitation, damages for loss of business profits, business interruption, or loss of business information), even if Polycom has been advised of the possibility of such damages.

**Customer Feedback** We are striving to improve our documentation quality and we appreciate your feedback. Email your opinions and comments to <mailto:DocumentationFeedback@polycom.com>.

**Polycom Support** Visit the [Polycom Support Center](#) for End User License Agreements, software downloads, product documents, product licenses, troubleshooting tips, service requests, and more.

# Contents

---

- Integrating Polycom Trio Systems with Zoom Rooms..... 2**
- Polycom Cameras Recommended for Zoom Rooms.....2
- Polycom UC Software and Zoom Rooms Software Integration..... 2
- Prerequisites..... 3
  - Polycom Trio System Prerequisites..... 3
  - Zoom Rooms Prerequisites.....3
- Configure your Polycom Trio System.....3
- Connect the Polycom Trio System.....3
- Complete Setup of the Zoom Room.....4

# Integrating Polycom Trio Systems with Zoom Rooms

---

## Topics:

- [Polycom Cameras Recommended for Zoom Rooms](#)
- [Polycom UC Software and Zoom Rooms Software Integration](#)
- [Prerequisites](#)
- [Configure your Polycom Trio System](#)
- [Connect the Polycom Trio System](#)
- [Complete Setup of the Zoom Room](#)

Polycom has teamed with Zoom to offer integration of Polycom Trio systems with Zoom Rooms. You can integrate the Polycom Trio system with Zoom Rooms as a Zoom Rooms controller, speaker, and microphone.

## Polycom Cameras Recommended for Zoom Rooms

Polycom now offers several camera options to integrate Polycom Trio system with Zoom Rooms. Polycom recommends matching a camera for your room size.

For more help and details on Polycom cameras, see [Peripherals](#) on Polycom Support.

Product	Software Version	Room Size
Polycom® EagleEye™ Mini USB camera	9.0.14	Small to medium room
Polycom® EagleEye™ IV USB camera	1.2	Medium to large room
Polycom® EagleEye™ Director II camera	2.1	Large to very large room

## Polycom UC Software and Zoom Rooms Software Integration

The Zoom Rooms control application is integrated with the Polycom UC Software running on the Polycom Trio system.

## Prerequisites

When configuring a Polycom Trio system with Zoom Rooms, there are prerequisites for the Polycom Trio system and for Zoom Rooms.

### Polycom Trio System Prerequisites

Polycom Trio system requires UC Software 5.7.1 or later to integrate with Zoom Rooms.

If you need to update your UC Software version, install UC Software using one of the following methods:

- Your own provisioning server. For information on setting up your own provisioning server, see the latest Polycom Trio System Administrator Guide on [Polycom Trio](#).
- Polycom® RealPresence® Resource Manager software. For details, see [RealPresence Resource Manager](#) on Polycom Support.
- Polycom Device Management System. For information, see [Polycom Device Management Service](#).
- The Web Configuration Utility for your Polycom Trio system provides a Software Upgrade feature to update software on a per-device basis. For information, see the latest Polycom Trio System Administrator Guide on [Polycom Trio](#).

### Zoom Rooms Prerequisites

Before you begin configuring Polycom Trio system with Zoom Rooms, complete the following Zoom Rooms prerequisites:

- To integrate Polycom Trio systems with Zoom Rooms, you must meet minimum Zoom Rooms system and hardware requirements listed on [System Requirements for Zoom Rooms](#) on the Zoom Help Center.
- Ensure the PC/Mac® computer is running the latest Zoom Rooms software as Zoom has enhanced their software to work with the Polycom Trio system.

## Configure your Polycom Trio System

Configure a few settings on the Polycom Trio system after you complete Polycom Trio system prerequisites. You can configure these settings using same method you used to complete the system prerequisites.

### Procedure

1. To enhance security, change the default administrator password (456) on your Polycom Trio system to a non-default password.
2. Ensure that the Polycom Trio system is configured with a valid time server and the correct time zone.
3. Set the Polycom Trio system Base Profile to **Zoom Rooms**.

## Connect the Polycom Trio System

After you configure your Polycom Trio system, set up and connect your hardware.

**Procedure**

1. Connect your USB camera to the PC/Mac® computer.
2. Connect the Polycom Trio system to the PC/Mac computer by USB cable.
3. Connect the Polycom Trio system to a network using a local area network (LAN) cable with Power over Ethernet (PoE). The Polycom Trio system automatically boots up.  
If PoE isn't available, you can use the optional Polycom Trio system power supply/power injector kit to provide PoE+ and full functionality to the Polycom Trio system.
4. Turn on your PC/Mac computer. A pairing code displays on the PC/Mac computer monitor.

## Complete Setup of the Zoom Room

After you connect your hardware, complete setup of the Zoom Room. To complete this procedure, you need the pairing code that displays on the Polycom Trio system.

**Procedure**

1. After the Polycom Trio system boots up, sign in to Zoom Rooms. For instructions, see [Signing In To Zoom Rooms](#) on the Zoom Help Center. After you complete the sign in steps, the Zoom Room is activated with a Zoom account.
2. Verify that the Polycom Trio system is selected as the microphone and speaker for the Zoom Room. You can complete this step on the Zoom Rooms controller interface on the Polycom Trio system or in the Zoom portal.
3. On the Zoom Room application on the Polycom Trio system screen, verify that the time shown is correct.