



ADMINISTRATOR GUIDE

5.0.0 | September 2015 | 3725-66892-003A

Polycom® RealPresence Immersive Telepresence (ITP)



Copyright© 2015, Polycom, Inc. All rights reserved. No part of this document may be reproduced, translated into another language or format, or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of Polycom, Inc.

6001 America Center Drive
San Jose, CA 95002
USA

Trademarks Polycom®, the Polycom logo and the names and marks associated with Polycom products are trademarks and/or service marks of Polycom, Inc. and are registered and/or common law marks in the United States and various other countries.



All other trademarks are property of their respective owners. No portion hereof may be reproduced or transmitted in any form or by any means, for any purpose other than the recipient's personal use, without the express written permission of Polycom.

Disclaimer While Polycom uses reasonable efforts to include accurate and up-to-date information in this document, Polycom makes no warranties or representations as to its accuracy. Polycom assumes no liability or responsibility for any typographical or other errors or omissions in the content of this document.

Limitation of Liability Polycom and/or its respective suppliers make no representations about the suitability of the information contained in this document for any purpose. Information is provided "as is" without warranty of any kind and is subject to change without notice. The entire risk arising out of its use remains with the recipient. In no event shall Polycom and/or its respective suppliers be liable for any direct, consequential, incidental, special, punitive or other damages whatsoever (including without limitation, damages for loss of business profits, business interruption, or loss of business information), even if Polycom has been advised of the possibility of such damages.

End User License Agreement By installing, copying, or otherwise using this product, you acknowledge that you have read, understand and agree to be bound by the terms and conditions of the End User License Agreement for this product. The EULA for this product is available on the Polycom Support page for the product.

Patent Information The accompanying product may be protected by one or more U.S. and foreign patents and/or pending patent applications held by Polycom, Inc.

Open Source Software Used in this Product This product may contain open source software. You may receive the open source software from Polycom up to three (3) years after the distribution date of the applicable product or software at a charge not greater than the cost to Polycom of shipping or distributing the software to you. To receive software information, as well as the open source software code used in this product, contact Polycom by email at OpenSourceVideo@polycom.com.

Customer Feedback We are striving to improve our documentation quality and we appreciate your feedback. Email your opinions and comments to DocumentationFeedback@polycom.com.

Polycom Support Visit the [Polycom Support Center](#) for End User License Agreements, software downloads, product documents, product licenses, troubleshooting tips, service requests, and more.

Before You Begin

This guide is intended for administrators who need to configure, customize, manage, and troubleshoot Polycom® RealPresence Immersive Studio™ and Polycom® RealPresence® OTX® Studio systems. Refer to this guide after installation of the furniture and video communication systems is complete.

Please read the RealPresence Immersive Studio and RealPresence OTX Studio system documentation before you install or operate the system. Related documents for RealPresence Immersive Studio and RealPresence OTX Studio systems are available from the [Polycom Video Documentation Support](#) site.

For support or service, please contact your Polycom distributor or go online to [Polycom Support](#).

Get Help

For more information about installing, configuring, and administering Polycom products, refer to **Documents and Downloads** at [Polycom Support](#).

The Polycom Community

The [Polycom Community](#) gives you access to the latest developer and support information. Participate in discussion forums to share ideas and solve problems with your colleagues. To register with the Polycom Community, simply create a Polycom online account. When logged in, you can access Polycom support personnel and participate in developer and support forums to find the latest information on hardware, software, and partner solutions topics.

Contents

Before You Begin	3
Get Help	3
The Polycom Community	3
Conventions Used in This Guide	10
Information Elements	10
Typographic Conventions	11
Introduction	12
RealPresence OTX Studio Monitor Lifts	12
Automatically Control Monitor Lifts	12
Manually Control Monitor Lifts	12
Control the Monitor Lifts from the Web Interface	12
Power On Self Test (POST)	13
Obtain the Network Parameters	13
Place Calls and Manage Contacts	14
View the Home Page	14
Place a Call	14
Call a Favorites Contact	14
Place a Call Manually	14
Call a Speed Dial Contact	15
Use Directories	15
Directory Capacity	15
Manage Favorites	16
Create a New Favorite Contact	16
Create a Favorites Group	16
Edit a Favorites Group	17
Delete a Favorites Contact or Group	17
Add a Speed Dial Contact	17
Remove a Speed Dial Contact	17
Types of Favorites Contacts	18

Configure the Admin Settings	19
General Settings	19
Contact and Location Information	19
System Contact	19
Location	20
System Settings	20
System Name	20
Call Settings	21
Recent Calls	22
Remote Control, Keypad, and Power Settings	22
Polycom VisualBoard™ Application	22
Home Screen Settings	22
Background Image	22
Pairing Settings	23
Polycom Touch Device	23
SmartPairing	23
Language	24
Date and Time	24
RS-232 Serial Port Settings	25
Enable Software Options	25
Software Updates	26
Networks	26
LAN Status Lights	27
LAN Properties	27
IP Network Settings	30
Network Quality Setting	30
H.323 Settings	31
SIP Settings	31
Configure SIP Settings for Integration with the Telepresence Interoperability Protocol (TIP)	34
RTV and Lync-Hosted Conference Support	34
Specify Quality of Service	35
Configuring Dialing Preferences	36
Audio/Video Settings	37
Monitors	37
Sleep	37
Use Sleep Settings to Prevent Monitor Burn-In	37
Video Inputs	38
Audio	38
Security Settings	39

Security Profiles	39
Global Security	39
External Authentication	39
Access	41
Encryption Settings	42
Local Account Settings	44
Account Lockout	44
Login and Credentials	45
Password Requirements	46
Manage Certificates and Revocation	47
Generate Certificate Signing Requests (CSRs)	48
Install Certificates	49
Configure Certificate Validation Settings	50
Configure Certificate Revocation Settings	51
Certificates and Security Profiles within a Provisioned System	53
RealPresence Server Address Configuration in PKI-Enabled Environments	54
Security Banners	54
Log Management	54
Configure Servers	55
Set Up a Directory Server	55
Use a Provisioning Service	57
Enable or Disable the Provisioning Service	58
Provisioning Service Settings	58
Connect to the Microsoft Exchange Server Calendaring Service	59
Set Up the Distributed Media Service	60
Configure the Distributed Media Service	62
Immersive Settings	63
Room Control Devices	63
Configure the Diagnostic Settings	64
Polycom RealPresence Manageability Instrumentation Solution	64
Web Interface Diagnostics Screens	64
System Diagnostics	65
System Information	65
Call Statistics	65
System Status	66
Download Logs	67
System Log Settings	67
Restart System	68
Sessions	68

Audio and Video Tests	68
Audio Meters	68
Calibrate the Microphone	69
Configure the Utilities Settings	70
Manage System Profiles	70
Store a Profile	70
Upload a Profile	70
Call Detail Report (CDR)	71
Enable CDR	71
View and Download the CDR	71
Information in the Call Detail Report (CDR)	71
Send a Message	74
Monitor a Room or Call	75
Display a Closed Caption	75
Security Profile Definitions	76
Configure the Low Security Profile	76
Configure Polycom RealPresence Touch	82
Perform the RealPresence Touch Out-of-Box Setup	82
Pair RealPresence Touch with RealPresence Immersive Studio or RealPresence OTX Studio.	82
Customize the RealPresence Touch Home Screen	83
Choose Icon Buttons That Display on the RealPresence Touch Home Screen	83
Customize the Place a Call Screen Icon Buttons on the RealPresence Touch Device ..	84
Change the Background Image of the Home Screen on the RealPresence Touch Device	84

Tables

Icons Used in this Guide	10
Typographic Conventions	11
Guidelines for Entering Contact Addresses	16
Types of Favorites Contacts	18
Optional Contact Information	19
Location Settings	20
System Call Settings	21
Security Profiles and SmartPairing	23
System Time Settings	24
Time in Call Settings	25
LAN Status Lights	27
IP Address (IPv4) Settings	27
LAN Options	28
Network Quality Settings	30
H.323 Settings	31
SIP Settings	32
SIP Address Naming Convention	33
Quality of Service Settings	35
Dialing Options and Preferred Speeds	36
General Audio Settings	38
Audio Input Settings	39
Audio Output Setting	39
Authentication Settings	40
Access Settings	41
Encryption Settings	43
Account Lockout Settings	44
Login Credentials	45
Password Policy Settings	46
Log Management Settings	55
Directory Servers Supported in Standard Operating Mode	56
Directory Servers Supported by Polycom RealPresence Resource Manager Provisioning	56
LDAP Server Settings	57
Microsoft Directory Server Settings	57

Provisioning Service Settings	59
Calendaring Settings	59
Multipoint Server Settings	62
Room Device Settings	63
System Log Settings	67
Call Detail Report Information	72
Low Security Profile Settings	76








Conventions Used in This Guide

This guide contains terms, graphical elements, and a few typographic conventions. Familiarizing yourself with these terms, elements, and conventions will help you successfully perform tasks.

Information Elements

This guide may include any of the following icons to alert you to important information.

Icons Used in this Guide

Name	Icon	Description
Note		The Note icon highlights information of interest or important information needed to be successful in accomplishing a procedure or to understand a concept.
Caution		The Caution icon highlights information you need to know to avoid a hazard that could potentially impact device performance, application functionality, or successful feature configuration.
Warning		The Warning icon highlights an action you must perform (or avoid) to prevent issues that may cause you to lose information or your configuration setup, and/or affect phone, video, or network performance.
Web Info		The Web Info icon highlights supplementary information available online such as documents or downloads on support.polycom.com or other locations.
Administrator Tip		The Administrator Tip icon highlights techniques, shortcuts, or productivity related tips.
User Tip		The User Tip icon highlights techniques, shortcuts, or productivity related tips.
Troubleshooting		The Troubleshooting icon highlights information that may help you solve a relevant problem or to refer you to other relevant troubleshooting resources.

Typographic Conventions

A few typographic conventions, listed next, may be used in this guide to distinguish types of in-text information.

Typographic Conventions

Convention	Description
Bold	Highlights interface items such as menus, menu selections, window and dialog names, soft keys, file names, and directory names when they are involved in a procedure or user action. Also used to highlight text to be entered or typed.
<i>Italics</i>	Used to emphasize text, to show example values or inputs (in this form: <i><example></i>), and to show titles of reference documents available from the Polycom Support Web site and other reference sites.
Blue Text	Used for cross references to other sections within this document and for hyperlinks to external sites and documents.
<code>Courier</code>	Used for code fragments and parameter names.

Introduction

The Polycom® RealPresence Immersive Studio™ system and Polycom® RealPresence® OTX® Studio system are state-of-the-art visual collaboration tools. With crisp, clean video and crystal-clear sound, Polycom RealPresence Immersive Studio and Polycom RealPresence OTX Studio systems provide natural video conferencing interaction using the most robust video communications technology.



Note: Video Network Operations Center (VNOC) services

If your organization has signed on for Video Network Operations Center (VNOC) services, the VNOC will handle many telepresence conferencing tasks for you.

RealPresence OTX Studio Monitor Lifts

You can raise or lower RealPresence OTX Studio table monitor lifts for optimum conference viewing. The monitor lifts are partially automated and can also be manually controlled.

Automatically Control Monitor Lifts

All three monitors automatically raise or lower in the following circumstances:

- When content is started the monitors rise.
- When content is used during a call and the call ends, the monitors lower.
- When the system powers on or during a restart the monitors lower. During initial start-up and restarts all monitor controls are locked.

Manually Control Monitor Lifts

After initial start-up, the individual buttons in the RealPresence OTX Studio table toggle the state of the associated lift. Full extension or retraction takes about 15 seconds. If you use the buttons while the monitors are moving, the direction the monitors are traveling reverses. The monitors will only fully stop in the middle of travel during a mechanical collision or a system power failure.

Control the Monitor Lifts from the Web Interface

You can raise or lower all three monitors from the web interface.

To raise or lower monitors from the web interface:

- » Go to **Utilities > Tools > OTX Setup** and select **Up** or **Down**.

Power On Self Test (POST)

When the power is cycled, the RealPresence Immersive Studio system automatically performs a system health check before initialization. This process is known as a power on self test, or POST. All test results are logged in the system's memory.

When the POST sequence completes with no severe errors, the RealPresence Immersive Studio system starts normally. If a severe error occurs, the system will not initialize. In that case, contact Polycom technical support.

Obtain the Network Parameters

To perform some of the configuration tasks in this document, you must obtain the proper network parameters.

To obtain the network parameters:

Obtain the following network parameters from the customer.

- Subnet Mask
- Default Gateway
- IP addresses
 - A block of 20 static IP addresses is required.
 - The base IP should be identified (for example, 10.10.10.x).
 - Define x as an offset (for example, 50).
 - The IP addresses should be assigned as shown in the next table.

IP Address Map

...x+	Device	...x+	Device
1	GS 700 (A1)	11	Display1 (D1)
2	GS 500 (A2)	12	Display2 (D2)
3	GS 500 (A3)	13	Display3 (D3)
4	<Reserved>	14	<Reserved>
5	SoundStructure	15	<Reserved>
6	Nport	16	Lutron NWK
7	<Reserved>	17	APC (PWR1)
8	DisplayMatrix	18	APC (PWR2)
9	<Reserved>	19	APC (PWR3)
10	Tablet	20	Ethernet Switch (if required)

Place Calls and Manage Contacts

This section describes how to place calls and manage contacts in the RealPresence Immersive Studio and RealPresence OTX Studio systems.

View the Home Page

When you select the **Place a Call** link on the web interface, the default view shows you the operations that you can perform:

- Place a Call
- Speed Dial

Place a Call

There are several methods for placing a call. Most require that you have stored information about the contacts you want to call. For procedures on storing contact information, refer to [Manage Favorites](#).

Call a Favorites Contact

You can search for a contact in your Favorites list.

To call a Favorites contact:

- 1 In the **Contacts** section, enter a name and select **Search**.
- 2 Select a contact name, and select **Call**.

Place a Call Manually

You can place a call by dialing manually.

To place a call manually:

- 1 Select **Manual Dial**.
- 2 Enter the number.
- 3 To enter a password to dial into an H.323 call on a standalone Group Series that is configured to require a password, select **Meeting Password**, and enter a password in the field that is displayed below the check box.

4 Select **Call**.

The call is placed according to the default settings you selected in **Admin Settings > Network > Dialing Preferences**. You can select options other than the defaults in the two drop-down lists below the text entry field.

Call a Speed Dial Contact

You can make a call by choosing a contact from the Speed Dial list.

To call a speed dial contact:

- » In the **Speed Dial** section, select a contact from the list, and select **Call**.

Use Directories

Storing frequently-used contacts and groups in the directory can help users find calling information quickly and easily. Polycom RealPresence Immersive Studio systems support global groups and Favorites groups.

Directory Capacity

RealPresence Immersive Studio systems support up to 2,000 Favorites that users create within Favorites. RealPresence Immersive Studio systems can also support one of the following:

- Up to 200 additional contacts with presence, which appear in Favorites, when registered with Microsoft Lync Server 2013 or Skype for Business Server 2015.
- Up to 200 additional contacts with presence, which appear in Favorites, when registered with Polycom RealPresence Resource Manager.
- An unlimited number of contacts when the RealPresence Immersive Studio system is registered with Microsoft Lync Server 2013 or Skype for Business Server 2015.

Polycom RealPresence Immersive Studio systems support up to 200 Favorites groups that users create within Favorites. If the system is connected to a global directory server, it can also support one of the following:

- Up to 64 additional groups from the Microsoft Lync Server, which appear in the Favorites group.
- Up to 200 additional distribution groups from Polycom RealPresence Resource Manager, which appear in the Global Directory group.

Manage Favorites

You can enter frequently called contacts as Favorites to facilitate dialing. The following table shows how to enter Favorite addresses.

Guidelines for Entering Contact Addresses

System or Address Type	Format or Sequence for Entering Addresses, Separated by Semicolons
Two screens	Right; Left.
Three screens	Center; Left; Right.
Four screens	Center right; Center Left; Far Right; Far Left
Meeting Room/Bridge	Enter the VMR Number three times for the fastest connection.
H.323 Address	Enter the H.323 alias or E.164 extension in the H.323 field. Note: Avoid entering an H.323 address and a SIP address in the same Favorite entry.

Create a New Favorite Contact

You can create a new Favorite contact not currently included in the Directory list.

To create a new Favorite contact that is not in the Directory list:

- 1 Go to **Manage Favorites**, and select **Create New Favorite**.
- 2 Enter the contact call information.
- 3 Select **Save**.

Create a Favorites Group

You can create a new group of Favorites.

To create a Favorites group:



Note: Dialing from a group is not supported.

- 1 Go to **Manage Favorites**, and select **Create New Group**.
- 2 Enter a **Display Name** for the group, and select **Save**.
A success message is displayed.
- 3 To add contacts to the group, select **Add Contacts** on the success message.
- 4 Enter a contact name in the search box, and select **Search**.
- 5 In the entry you want to add to the group, select **Add**.
- 6 Repeat the above steps to add more contacts to the group.

- 7 Select **Done**.

Edit a Favorites Group

You can edit a Favorites group to add or remove contacts.

To edit a Favorites group:

- 1 Find the group name in the list of contacts.
- 2 Next to the group contact name, select **Edit Group**.
Do one of the following:
 - To add contacts to the group, select **Add From Directory**, enter a contact name, select **Search**, and then **Add** to add a contact.
 - To remove contacts from the group, select a contact name and select **Remove**.
- 3 Repeat the above steps to continue adding or removing contacts.
- 4 Select **Done**.

Delete a Favorites Contact or Group

You can delete a contact or a complete group from Favorites.

To delete a Favorites contact or group:

- 1 In the search box, type a contact name and select **Search**.
- 2 In the contact name you want to delete, select **Delete**.

Add a Speed Dial Contact

You can add a new contact to a Speed Dial list.

To add a speed dial contact:

- 1 Go to **Place a Call > Speed Dial** and select **Edit**.
- 2 Enter a contact name, and select **Search**.
- 3 In the contact you want to add, select **Add**.
- 4 To save your changes, select **Done**.

Remove a Speed Dial Contact

You can remove a contact from a Speed Dial list.

To remove a speed dial contact:

- 1 Go to **Place a Call > Speed Dial** and select **Edit**.
- 2 In the contact you want to delete, select **Remove**.
- 3 To save your changes, select **Done**.

Types of Favorites Contacts

Favorites contains the types of Contacts shown in the following table.

Types of Favorites Contacts

Directory Server Registration	Types of Contacts	Presence State Displayed
Polycom GDS	Not supported.	
LDAP with H.350 or Active Directory	<ul style="list-style-type: none"> • Directory entries created locally by the user • References to LDAP directory entries added to Favorites by the user. <p>These entries are available only if the system can successfully access the LDAP/Active Directory server. Administrators can delete these entries from Favorites. Administrators can copy these entries to other Favorites and remove them from those groups. Non-administrative users cannot edit these entries.</p>	Unknown
LDAP by a Polycom RealPresence Resource Manager System	<ul style="list-style-type: none"> • Directory entries created locally by the user. • References to LDAP directory entries added to Favorites by the user. <p>These entries are available only if the system can successfully access Polycom RealPresence Resource Manager. Administrators can delete these entries from Favorites. Administrators can copy these entries to other Favorites and remove them from those groups. Non-administrative users cannot edit these entries.</p>	Unknown
	<p>LDAP directory entries saved as Favorites by the user and stored with the presence service. Administrators can delete these entries from Favorites. Administrators can copy these entries to other Favorites and remove them from those groups. Non-administrative users cannot edit these entries.</p>	Real-time presence
Microsoft	<p>Microsoft Lync Server directory entries saved as Contacts by the user in Office Communicator and stored on the Microsoft Lync Server.</p> <p>Administrators must create their contact lists using Microsoft Office Communicator on a computer. Administrators can copy these entries to other Favorites and remove them from those groups. Users cannot edit or delete these entries from Favorites using the Polycom RealPresence Immersive Studio system.</p>	Real-time presence

Configure the Admin Settings

General Settings

Some of the information saved in these settings is not used in this release of the RealPresence Immersive Studio or RealPresence OTX Studio.

Contact and Location Information

You can specify contact information for your RealPresence Immersive Studio or RealPresence OTX Studio system so that others know whom to call when they need assistance.

System Contact

You can specify system contact information for your RealPresence Immersive Studio or RealPresence OTX Studio system.

To specify system contact information:

- 1 Go to **Admin Settings > General Settings > My Information > Contact Information**.
- 2 Configure these settings.

Optional Contact Information

Setting	Description
Contact Person	Specifies the name of the system administrator.
Contact Number	Specifies the phone number for the system administrator.
Contact Email	Specifies the email address for the system administrator.
Contact Fax	Specifies the fax number for the system administrator.
Tech Support	For RealPresence Immersive Studio specifies the name of the person who provides technical support. For RealPresence OTX Studio specifies the help desk phone number.
City	Specifies the city where the system administrator is located.
State/Province	Specifies the state or province where the system administrator is located.
Country	Specifies the country where the system administrator is located.

You can also specify regional settings.

Location

You can specify location settings for your RealPresence Immersive Studio system.

To configure location settings:

- 1 Go to **Admin Settings > General Settings > My Information > Location**.
- 2 Configure these settings.

Location Settings

Setting	Description
Country	Specifies the country where the system is located. Changing the country automatically adjusts the country code associated with your system.
Country Code	Displays the country code associated with the country where the system is located.

System Settings

The System Settings screen provides access to high-level options for the entire system.

System Name

The System Name screen enables you to name your system and your center, left, and right server names.

To configure a system name:

- 1 Go to **Admin Settings > General Settings > System Settings > System Name**.



Note: The first character of a System Name

The first character of a System Name must be a letter or a number. The System Name cannot begin with the dollar sign (\$) or underscore (_) character.

- 2 In the **System Name** field, enter a name as described below.

- » Enter the <SiteName>[TYPE OF ITP].

“[TYPE OF ITP]” is optional and specifies the type of ITP room: “RIS” for RealPresence Immersive Studio

When you assign a system name for the main codec, unique identities for the left and right codecs are automatically generated. The naming convention is as follows.

<SiteName>[TYPE OF ITP]_M_N where:

- ◆ M = number of systems (for RealPresence Immersive Studio, this value is 3)
- ◆ N = 1 for the primary system, 2 for the left system, and 3 for the right system

**Note: TYPE OF ITP field**

The TYPE OF ITP field enables Polycom Multipoint Layout Application to find the correct Immersive Studio or OTX Studio room, when the Immersive Studio or OTX Studio room is part of a telepresence conference participants list, but disconnected from the conference.

The system name is displayed on the screen for the far site when you are in a call.

3 Select Save.**Note: When naming the sites, keep the following in mind:**

Do not use site names which are the same or similar (site names with a trailing numeral digit, for instance) for Group Series codecs that are part of Immersive Studio or OTX Studio room systems and for individual endpoints that are not part of Immersive Studio or OTX Studio room systems. When individual endpoints, disconnected from a telepresence conference, use the same or similar names as each other and as Immersive Studio or OTX Studio systems, then Polycom MLA sometimes mistakenly identifies the individual endpoints as Immersive Studio, OTX Studio, or ITP systems.

Call Settings

The call settings screen enables you to determine which settings are available to users when they place and answer calls.

To configure call settings:

- 1 In the primary codec web UI, go to **Admin Settings > General Settings > System Settings > Call Settings**.
- 2 Configure these settings.

System Call Settings

Setting	Description
Maximum Time in Call	<p>Enter the maximum number of hours allowed for call length.</p> <p>When that time has expired, you see a message asking whether you want to hang up or stay in the call. If you do not answer within one minute, the call automatically disconnects. If you choose to stay in the call at this time, you will not be prompted again.</p> <p>Selecting Off removes any limit.</p> <p>This setting also applies when you are viewing the Near video screen or showing content, even if you are not in a call. If the maximum time is reached while viewing Near video, the system automatically returns to the Home screen. If content is being shown, the content stops.</p>
Auto Answer Point-to-Point Video	<p>Sets the answer mode for calls with one site.</p> <ul style="list-style-type: none"> • Yes—Answers calls automatically. • No—Enables you to answer calls manually. • Do Not Disturb—Disables incoming calls from being processed.

System Call Settings

Setting	Description
Enable Flashing Incoming Call Notification	Select check box to enable flashing for incoming calls.
Preferred 'Place a Call' Navigation	Sets the preferred method to place a call. <ul style="list-style-type: none"> • Dial Pad • Contacts

Recent Calls

Generating a Call Detail Report is supported in the RealPresence Immersive Studio system. Note that **Clear Recent Calls** is not supported.

To enable generating a Call Detail Report:

- 1 Go to **Admin Settings > General Settings > System Settings > Recent Calls**.
- 2 Select **Call Detail Report**.

Remote Control, Keypad, and Power Settings

These functions are not supported in the RealPresence Immersive Studio system.

Polycom VisualBoard™ Application

The Polycom VisualBoard™ application allows you to show and annotate content in real time from Polycom RealPresence Group systems by using a touch display.

To enable the VisualBoard application:

- 1 In the primary codec web interface, go to **Admin Settings > General Settings > System Settings > VisualBoard**.
- 2 Select **Enable** and click **Save**.

Home Screen Settings**Background Image**

The RealPresence Immersive Studio system and the OTX Studio system displays a blank wallpaper; however, three optional wallpaper images are available from the web interface.

To change the background image:

- 1 Go to **Admin Settings > General Settings > Home Screen Settings > Wall Paper**.
- 2 Select the image that you want to use. The selected image is displayed on the main monitor and on the tablet.

Pairing Settings

Specify pairing settings to enable touch devices to pair with the system.

Polycom Touch Device

Select **Enable Polycom Touch Device** to enable the touch device to operate the system.

SmartPairing

SmartPairing allows you to detect and pair a RealPresence Immersive Studio or RealPresence OTX Studio system from the RealPresence Mobile application on an Android or Apple iPad tablet. After you pair the application and the RealPresence Immersive Studio or RealPresence OTX Studio system, you can use the RealPresence Mobile application to send content from the RealPresence Mobile application to the RealPresence Immersive Studio or RealPresence OTX Studio system.

Be aware that Telnet must be enabled before you can use SmartPairing. Because Telnet is disabled by default in all Security Profiles, SmartPairing is also disabled by default. The Telnet enable setting is not configurable when the **Security Profile** is set to Maximum or High.

Security Profiles and SmartPairing

Security Profile	Telnet Setting Default	SmartPairing Available?
Maximum / High	Disabled, Not Configurable	No
Medium / Low	Disabled, Configurable	Yes. To use SmartPairing, do the following: <ol style="list-style-type: none"> 1 Enable Telnet. 2 Send API command or use web interface.

To configure SmartPairing:

- 1 In the web interface, go to **Admin Settings > General Settings > Pairing > SmartPairing**.
- 2 Configure these settings.

Setting	Description
SmartPairing Mode	Specifies the method used to pair with the RealPresence Immersive Studio system, if SmartPairing is enabled: <ul style="list-style-type: none"> • Disabled • Automatic • Manual
Signal Volume	Specifies the relative signal strength of the ultrasonic signal within the loudspeaker audio output signal.



Note: Paired device

Each paired device is displayed in **Diagnostics > System > Sessions**.

Language

This function is not supported in this release of the RealPresence Immersive Studio system.

Date and Time

System Time settings enable you to specify how date and time values are displayed.

To configure date and time settings:

- 1 Go to **Admin Settings > General Settings > Date and Time > System Time**.
- 2 Configure these settings.

System Time Settings

Setting	Description
Date Format	Specifies how the date is displayed in the interface.
Time Format	Specifies how the time is displayed in the interface.
Auto Adjust for Daylight Saving Time	Specifies the daylight saving time setting. When you enable this setting, the system clock automatically changes for daylight saving time.
Time Zone	Specifies the time difference between Greenwich Mean Time (GMT) and your location.
Time Server	Specifies whether the connection to a time server is automatic or manual for system time settings. You can also select Off to enter the date and time yourself.
Primary Time Server Address Secondary Time Server Address	Specifies the address of the primary and optional secondary time servers to use when Time Server is set to Manual . The system uses the secondary time server if the primary time server does not respond.
Current Date Current Time	If Time Server is set to Off , these settings are configurable.

You can also choose whether and how to display the time spent in a call.

To configure Time in Call settings:



Note: Time in Call settings

Time in Call settings are displayed on the web interface.

- 1 Go to **Admin Settings > General Settings > Date and Time > Time in Call**.
- 2 Configure these settings.

Time in Call Settings

Setting	Description
Show Time in Call	Specifies the time display in a call: <ul style="list-style-type: none"> • Elapsed Time—Displays the amount of time in the call. • System Time—Displays the system time on the screen during a call. • Off—Time is not displayed.
When to Show	Specifies when the time should be shown: <ul style="list-style-type: none"> • Start of the call only—Displays only when the call begins • Entire call—Displays continuously throughout the call • Once per hour—Displays at the beginning of the hour for one minute • Twice per hour—Displays at the beginning of the hour and midway through the hour for one minute
Show Countdown Before Next Meeting	When enabled, it displays a timer that counts down to the next scheduled meeting 10 minutes before that meeting. If a timer is already showing, the countdown timer replaces it 10 minutes before the next scheduled meeting.

RS-232 Serial Port Settings

This option is not supported in this release of the RealPresence Immersive Studio or RealPresence OTX Studio system.

Enable Software Options

Some of the features of a RealPresence Immersive Studio system are optional. To activate these features, you must enter a key code using the provided license.

Go to **Admin Settings > General Settings > Options** to enter the key code.

Enable the following options on the primary system:

- **Telepresence Interoperability Protocol (TIP)**. This option provides the best possible telepresence experience when interoperating with Cisco TelePresence® rooms equipment.
- **Skype for Business Interoperability License**. This option enhances the video experience by enabling the use of the Microsoft RTV video codec, which provides higher resolutions during video calls when integrated with Microsoft Lync Server.
 - Centralized Conferencing Control Protocol (CCCP) enables seamless participation in multipoint video conferences hosted on Lync's audio/video server.
 - IPv6 is supported in Lync 2013, Skype for Business Server 2015, and Skype for Business 2015 client environments with IPv6 networks.

For information about integrating with Microsoft Lync Server, refer to the [Polycom Unified Communications Deployment Guide for Microsoft Environments](#).

- **Advanced Video 1080p License**. This option makes 1080p video and content available to RealPresence Immersive Telepresence systems.
- **RealPresence Immersive Studio**. This option identifies the Polycom video conferencing system that you are using.

Software Updates

You can update your Polycom RealPresence Immersive Studio system by going to support.polycom.com, navigating to **Documents and Downloads > Telepresence and Video**, and then downloading and installing the appropriate software.

You can also have your system automatically check for and apply software updates.

To install software updates:

- 1 Go to **Admin Settings > General Settings > Software Updates > Software Server**.
- 2 Enter the address of the server on which the software is loaded.
- 3 Select **Check for Software Updates**.
- 4 When an available update is displayed, select **Start Update**.

To install software updates manually:

- 1 Go to **Admin Settings > General Settings > Software Updates > Manual Software Updates**.
- 2 Browse to locate the software update package on your PC and select **Start Transfer** to download it to the Group Series codec and start the update.
- 3 Repeat steps 1 and 2 for the left and right Group Series codecs.

To configure the system to check for software updates:

- 1 Go to **Admin Settings > General Settings > Software Updates > Automatic Software Updates**.
- 2 Select **Automatically Check for and Apply Software Updates**.
- 3 Accept the license agreement.
- 4 In the **Start Time** field, specify the hour, minute, and AM/PM settings to start checking for updates.
- 5 In the **Duration** field, specify how long the system should wait to determine whether updates are available

Refer to the [Polycom RealPresence Immersive Telepresence \(ITP\) Release Notes](#) information about the latest software version, including version dependencies.



Note: Automatic software updates

If your organization uses a management system for provisioning endpoints, your Polycom RealPresence Immersive Studio system might get software updates automatically.

Networks

Before you begin configuring the network options, you must make sure your network is ready for video conferencing.

Polycom also offers contract high-definition readiness services. For more information, contact your Polycom distributor.

LAN Status Lights

The LAN connector on the RealPresence Group systems has two lights to indicate connection status and traffic.

LAN Status Lights

Indicator Light	Connection Status
Left light off	No 1000Base-T connection.
Left light green	1000Base-T connection.
Right light off	No 10/100 Base-T connection and no network traffic with 1000 Base-T connection.
Right light on	10/100 Base-T connection and blinks with network traffic.
Right light blinking	Network traffic.

LAN Properties

You can configure LAN properties for the RealPresence Immersive Studio.



Note: Configure each system individually.

LAN properties are controlled individually by the three systems that are part of the RealPresence Immersive Studio setup. You must configure each system individually.

To configure RealPresence Immersive Studio LAN properties:

- 1 In the primary codec web UI, go to **Admin Settings > Network > LAN Properties**.
- 2 Configure the following **IP Address (IPv4)** settings on the LAN Properties screen. A static IPv4 address is required for each codec.

IP Address (IPv4) Settings

Setting	Description
IP Address	Specifies how the system obtains an IP address. <ul style="list-style-type: none"> • Obtain IP Address Automatically—Select if the system gets an IP address from the DHCP server on the LAN. • Enter IP Address Manually—Select if the IP address will not be assigned automatically.
Your IP Address is	If the system obtains its IP address automatically, this area displays the IP address currently assigned to the system. If you selected Enter IP Address Manually , enter the IP address here.
Default Gateway	Displays the gateway currently assigned to the system. If the system does not automatically obtain a gateway IP address, enter one here.
Subnet Mask	Displays the subnet mask currently assigned to the system. If the system does not automatically obtain a subnet mask, enter one here.

- 3 The DNS Server address fields are populated automatically when the IPv4 Address is automatically obtained.

If the IPv4 address is not obtained automatically, enter the DNS Server addresses.

- 4 Configure the following **LAN Options** settings.

LAN Options

Setting	Description
Host Name	Indicates the system's DNS name.
Domain Name	Displays the domain name currently assigned to the system. If the system does not automatically obtain a domain name, enter one here.
Autonegotiation	Specifies whether the network switch should automatically negotiate the LAN speed and duplex mode. If this setting is enabled, the LAN Speed and Duplex Mode settings become read only. Polycom and IEEE802.3 recommend that you use autonegotiation to avoid network issues.
LAN Speed	Specifies whether to use 10 Mbps , 100 Mbps , or 1000 Mbps for the LAN speed. Note that the switch must support the speed that you choose.
Duplex Mode	Specifies the duplex mode to use. Note that the switch must support the Duplex mode that you choose.
Ignore Redirect Messages	Enables the RealPresence Group system to ignore redirect messages from network routers. A redirect message tells the endpoint to use a different router than the one it is using.
ICMP Transmission Rate Limit (millisec)	Specifies the minimum number of milliseconds between transmitted packets. Enter a number between 0 and 60000. The default value of 1000 signifies that the system sends 1 packet per second. If you enter 0, the transmission rate limit is disabled. This setting applies only to "error" ICMP packets. This setting has no effect on "informational" ICMP packets, such as echo requests and replies.
Generate Destination Unreachable Messages	Generates a <code>Destination Unreachable</code> message if a packet cannot be delivered to its destination for reasons other than network congestion.
Respond to Broadcast and Multicast Echo Requests	Sends an <code>Echo Reply</code> message in response to a broadcast or multicast Echo Request, which is not specifically addressed to the RealPresence Group system.
IPv6 DAD Transmit Count	Specifies the number of Duplicate Address Detection (DAD) messages to transmit before acquiring an IPv6 address. The RealPresence Immersive Studio system sends DAD messages to determine whether the address it is requesting is already in use. Select whether to transmit 0, 1, 2, or 3 DAD requests for an IPv6 address.
Enable PC LAN Port	The setting appears only for the RealPresence Immersive Studio main system. Specifies whether the PC LAN port is enabled on the back of the system. Disable this setting for increased security.

LAN Options

Setting	Description
Enable EAP/802.1X	Specifies whether EAP/802.1X network access is enabled. RealPresence Group systems support the following authentication protocols: <ul style="list-style-type: none"> • EAP-MD5 • EAP-PEAPv0 (MSCHAPv2) • EAP-TTLS • EAP-TLS
Enable 802.1p/Q	Specifies whether VLAN and link layer priorities are enabled.

Configure the IP Addresses of the Component Codecs

The following procedures describe how to change the IP addresses of the main and secondary codecs while they are **not** in **Immersive** mode. To take the system out of immersive mode, go to the Immersive page in the primary codec web UI and change **this system** from Primary to Standalone.

To change the IP address of the primary codec:

- 1 In the primary codec web UI, go to **Admin Settings > Network > LAN Properties** for the primary codec.
- 2 In the **IP Address (IPv4)** section, in the **IP Address** field, specify how the system obtains an IP address.
 - **Obtain IP Address Automatically**—Select this option if the system gets an IP address from the DHCP server on the LAN.
 - **Enter IP Address Manually**—Select this option if the IP address will not be assigned automatically.
 - 1 For the manual IP address option, enter the new information in the **Your IP Address is**, **Default Gateway**, and **Subnet Mask** fields.
 - 2 Save the changes.

After you changed the IP address of the primary codec, the secondary codecs might start the reboot cycle because they have lost connection with the primary codec. In addition, the primary display shows black video.

- 3 Go to **Admin Settings > Immersive**.
- 4 In the **Left Static IP Address** and **Right Static IP Address** fields, enter the updated IP addresses for the left and right secondary codecs respectively.
- 5 Enter **Admin ID** and **Password** credentials if you use them.
- 6 Select **Connect**. All codecs reboot.

To change the IP address of a secondary codec:

- 1 In the secondary codec web UI, go to **Admin Settings > Network > LAN Properties** for the secondary codec.
- 2 In the **IP Address (IPv4)** section, in the **IP Address** field, specify how the system obtains an IP address.
 - **Obtain IP Address Automatically**—Select this option if the system gets an IP address from the DHCP server on the LAN.
 - **Enter IP Address Manually**—Select this option if the IP address will not be assigned automatically.
 - 1 For the manual IP address option, enter the new information in the **Your IP Address is**, **Default Gateway**, and **Subnet Mask** fields.
 - 2 Save the changes.

After you change the IP address of the secondary codec, the codec might start the reboot cycle because it has lost the SSH connection to the primary codec. In addition, the main display shows black video.

- 3 Go to **Admin Settings > Immersive** for the primary codec.
- 4 Select the **RealPresence Immersive Studio** or **RealPresence OTX Studio** for the **System Type**.
- 5 In the **Left Static IP Address** or **Right Static IP Address** field, enter the updated IP address for the applicable secondary codec.
- 6 Enter **Admin ID** and **Password** credentials if you use them.
- 7 Select **Connect**. All codecs reboot.
- 8 As needed, repeat steps 1 through 7 for the remaining secondary codec.

IP Network Settings

You can configure IP network settings by going to **Admin Settings > Network > IP Network**.

Network Quality Setting

Use this group of settings to specify how your RealPresence Immersive Studio responds to quality issues.

Network Quality Settings

Setting	Description
Automatically Adjust People or Content Bandwidth	Specifies whether the system should automatically adjust the bandwidth necessary for the People stream or Content stream depending on the relative complexity of the people video, content video, or both. This setting is not available if you select a Quality Preference .
Quality Preference	Specifies which stream has precedence when attempting to improve network quality issues: <ul style="list-style-type: none"> • Both (People and Content Streams) • People Streams • Content Streams This setting is not available when the Automatically Adjust People/Content Bandwidth setting is enabled.

H.323 Settings

If your network uses a gatekeeper, the system can automatically register its H.323 name and extension. This enables others to call the system by entering the H.323 name or extension instead of the IP address.

To configure H.323 settings, in the web interface go to **Admin Settings > Network > IP Network > SIP**.

H.323 Settings

Setting	Description
Enable IP H.323	Enables the H.323 settings to be displayed and configured.
H.323 Name	Specifies the name that gatekeepers and gateways use to identify this system. You can make point-to-point calls using H.323 names if both systems are registered to a gatekeeper. The H.323 Name is the same as the System Name , and is automatically generated in the same way.
H.323 Extension (E.164) (for Left, Main, and Right Codecs)	Enables users to place point-to-point calls using the extension if both systems are registered with a gatekeeper, and specifies the extension that gatekeepers and gateways use to identify this system. Your organization's dial plan might define the extensions you can use.
Use Gatekeeper	Select this setting to use a gatekeeper. Gateways and gatekeepers are required for calls between IP and ISDN. <ul style="list-style-type: none"> • Off—Calls do not use a gatekeeper. • Auto—System attempts to automatically find an available gatekeeper. <ul style="list-style-type: none"> ▲ Current Gatekeeper IP Address—Displays the IP address that the gatekeeper is currently using. ▲ Primary Gatekeeper IP Address—Displays the gatekeeper's IP address. The primary gatekeeper IP address contains the IPv4 address with which the system registers. As part of the gatekeeper registration process, the gatekeeper might return alternate gatekeepers. If communication with the primary gatekeeper is lost, the RealPresence Group System registers with the alternate gatekeeper but continues to poll the primary gatekeeper. If the system reestablishes communications with the primary gatekeeper, the RealPresence Group System unregisters from the alternate gatekeeper and reregisters with the primary gatekeeper. • Specify—Calls use the specified gatekeeper. This option must be selected to enable H.235 Annex D Authentication. <ul style="list-style-type: none"> ▲ Require Authentication—Enables support for H.235 Annex D Authentication. When H.235 Annex D Authentication is enabled, the H.323 gatekeeper ensures that only trusted H.323 endpoints are allowed to access the gatekeeper. User Name—When authentication is enabled, specifies the user name for authentication with H.235 Annex D. Enter Password—When authentication is enabled, specifies the password for authentication with H.235 Annex D.

SIP Settings

If your network supports the Session Initiation Protocol (SIP), you can use SIP to connect IP calls.

To specify SIP Settings:

- 1 In the web interface, go to **Admin Settings > Network > IP Network > SIP**.
- 2 Configure these settings.

SIP Settings

Setting	Description
Enable SIP	Enables the SIP settings to be displayed and configured.
Enable AS-SIP	Not supported.
SIP Server Configuration	Specifies whether to automatically or manually set the SIP server's IP address. If you select Auto , the Transport Protocol, Registrar Server, and Proxy Server settings cannot be edited. If you select Specify , those settings are editable.
Transport Protocol	Indicates the protocol the system uses for SIP signaling. The SIP network infrastructure within which your RealPresence Immersive Studio operates determines which protocol is required. Auto enables an automatic negotiation of protocols in the following order: TLS, TCP, UDP. This is the recommended setting for most environments. TCP provides reliable transport via TCP for SIP signaling. UDP provides best-effort transport via UDP for SIP signaling. TLS provides secure communication of the SIP signaling. TLS is available only when the system is registered with a SIP server that supports TLS. When you choose this setting, the system ignores TCP/UDP port 5060.
Sign-in Address (for Left, Main, and Right Codecs)	Specifies the SIP address or SIP name of the system, for example, vineyarditp3@abc.com. If you leave this field blank, the system's IP address is used for authentication. Refer to SIP Address Naming Convention for details on the recommended naming convention for SIP addresses.
User Name (for Left, Main, and Right Codecs)	Specifies the name to use for authentication when registering with a SIP Registrar Server, for example, msmith@company.com. If the SIP proxy requires authentication, this field and the password cannot be blank.
Password (for Left, Main, and Right Codecs)	Specifies the password that authenticates the system to the Registrar Server.

SIP Settings

Setting	Description
Registrar Server	<p>Specifies the IP address or DNS name of the SIP Registrar Server.</p> <ul style="list-style-type: none"> In a Microsoft Lync Server 2013 or Skype for Business Server 2015 environment, specify the IP address or DNS name of the Lync Server server. If registering a remote RealPresence Immersive Studio with an Office Communications Server Edge Server or Lync Server Edge Server, use the fully qualified domain name of the access edge server role. <p>By default for TCP, the SIP signaling is sent to port 5060 on the registrar server. By default for TLS, the SIP signaling is sent to port 5061 on the registrar server.</p> <p>Enter the IP address and port using the following format: <IP_Address>:<Port> <IP_Address> can be an IPv4 address or a DNS hostname such as servername.company.com:6050. Hostnames can resolve to IPv4 addresses.</p> <p>Syntax Examples:</p> <ul style="list-style-type: none"> To use the default port for the protocol you have selected: 10.11.12.13 To specify a different TCP or UDP port: 10.11.12.13:5071
Proxy Server	<p>Specifies the DNS name or IP address of the SIP Proxy Server. If you leave this field blank, the Registrar Server is used. If you leave both the SIP Registrar Server and Proxy Server fields blank, no Proxy Server is used.</p> <p>By default for TCP, the SIP signaling is sent to port 5060 on the proxy server. By default for TLS, the SIP signaling is sent to port 5061 on the proxy server.</p> <p>The syntax used for this field is the same as for the Registrar Server field.</p>
Registrar Server Type	<p>If the registering server is Lync, select Microsoft. Otherwise, select Unknown.</p>

For more information about interoperability considerations for Polycom and Microsoft, refer to the [Polycom Unified Communications Deployment Guide for Microsoft Environments](#).

SIP Address Naming Convention

Polycom recommends using the following naming conventions for SIP addresses, but it is not required. The advantage of using this naming convention is that a Polycom Immersive endpoint (RPX, OTX, ATX, Immersive Studio, OTX Studio) can dial a call using a single SIP address such as vineyarditp3@abc.com and it will automatically dial the other addresses, ~vineyard2@abc.com and ~vineyard3@abc.com. This naming convention can be used for deployment with any type of SIP infrastructure.

SIP Address Naming Convention

Codec	Format	Example
Main codec	<name>itp<number_of_codecs>@<domain>	vineyarditp3@abc.com
Right codec	~<name><codec_number>@<domain>	~vineyard2@abc.com
Left codec	~<name><codec_number>@<domain>	~vineyard3@abc.com

Configure SIP Settings for Integration with Microsoft Servers

Integration with Microsoft Lync Server 2013 and Skype for Business Server 2015 enables Microsoft Lync and Polycom RealPresence Immersive Studio system users to place audio and video calls to each other.



Note: Presence services

Because Polycom RealPresence Immersive Studio systems run in dynamic management mode, they cannot be simultaneously registered with Lync Server and the presence service provided by the Polycom RealPresence Resource Manager system.

RealPresence Immersive Studio systems can obtain presence services from only one source: Lync Server, or the presence service provided by the RealPresence Resource Manager system.

Polycom supports the following features in Microsoft Lync Server 2013 and Skype for Business Server 2015:

- Interactive Connectivity Establishment (ICE)
- Centralized Conferencing Control Protocol (CCCP); this feature is available only with the optional license key
- Federated presence
- The Microsoft real-time video (RTV) codec; this feature is available only with the optional license key

For more information about this and other Microsoft/Polycom interoperability considerations, refer to the [Polycom Unified Communications Deployment Guide for Microsoft Environments](#).

If your organization deploys multiple Lync Server pools, a Polycom RealPresence Immersive Studio system must be registered to the same pool to which the system's user account is assigned.

Configure SIP Settings for Integration with the Telepresence Interoperability Protocol (TIP)

When SIP is enabled on a RealPresence Immersive Studio system that has the TIP option, the system can interoperate with TIP endpoints. Note that the Immersive Studio and OTX Studio systems do not support a TIP call to other Polycom equipment, whether an end point or RMX.



Note: Points to note about TIP:

- SIP (TIP) calls must connect at a call speed of 1 Mbps per screen or higher.
- Only TIP version 7 is supported.
- In a TIP call, only XGA content at 5 fps is supported. The following content sources are not supported in TIP calls:
 - ▲ USB content from the Polycom Touch Control
 - ▲ People+Content™ IP

For more information about Polycom support for the TIP protocol, refer to the [Polycom Unified Communications Deployment Guide for Cisco Environments](#).

RTV and Lync-Hosted Conference Support

To use RTV in a Lync-hosted conference, you must have the RTV option key enabled on your RealPresence Immersive Studio system.

For more information about configuring your Lync Server video settings for RTV, refer to the [Polycom Unified Communications Deployment Guide for Microsoft Environments](#).

Specify Quality of Service

Set the Quality of Service options for the way your network handles IP packets during video calls.

Lost Packet Recovery and Dynamic Bandwidth

You can handle video quality issues by selecting the **Enable Lost Packet Recovery** (LPR) setting, the **Dynamic Bandwidth** setting, or both settings.

If both settings are enabled, Dynamic Bandwidth adjusts the video rate to reduce packet loss to 3% or less. When packet loss drops to 3% or less, LPR cleans up the video image on your monitor. The additional processing power required might cause the video rate to drop while the system is using LPR. If this happens, the Call Statistics screen shows the Video Rate Used as lower than the Video Rate. If Packet Loss is 0 for at least 10 minutes, LPR stops operating and the Video Rate Used increases to match the Video Rate.

If only LPR is enabled and the system detects packet loss, LPR attempts to clean the image but the video rate is not adjusted. If only Dynamic Bandwidth is enabled and the system detects packet loss of 3% or more, the video rate is adjusted but LPR does not clean the image.

To configure quality of service settings:

- 1 Go to **Admin Settings > Network > IP Network > Network Quality**.
- 2 Configure these settings.

Quality of Service Settings

Setting	Description
Type of Service	Specifies your service type and lets you choose how to set the priority of IP packets sent to the system for video, audio, and far-end camera control: <ul style="list-style-type: none"> • IP Precedence—Represents the priority of IP packets sent to the system. The value can be between 0 and 5. • DiffServ—Represents a priority level between 0 and 63.
Video	Specifies the IP Precedence or Diffserv value for video RTP traffic and associated RTCP traffic.
Audio	Specifies the IP Precedence or Diffserv value for audio RTP traffic and associated RTCP traffic.
Control	Specifies the IP Precedence or Diffserv value for control traffic on any of the following channels: <ul style="list-style-type: none"> • H.323—H.225.0 Call Signaling, H.225.0 RAS, H.245, Far End Camera Control • SIP—SIP Signaling, Far End Camera Control, Binary Floor Control Protocol (BFCP)
OA&M	Specifies the IP Precedence or Diffserv value for traffic not related to video, audio, or FECC.
Maximum Transmission Unit Size	Specifies whether to use the default Maximum Transmission Unit (MTU) size for IP calls or select a maximize size.

Quality of Service Settings

Setting	Description
Maximum Transmission Unit Size Bytes	Specifies the MTU size, in bytes, used in IP calls. If the video becomes blocky or network errors occur, packets might be too large; decrease the MTU. If the network is burdened with unnecessary overhead, packets might be too small; increase the MTU.
Enable Lost Packet Recovery	Enables the system to use LPR (Lost Packet Recovery) if packet loss occurs.
Enable RSVP	Enables the system to use Resource Reservation Setup Protocol (RSVP) to request that routers reserve bandwidth along an IP connection path. Both the near site and far site must support RSVP in order for reservation requests to be made to routers on the connection path.
Dynamic Bandwidth	Specifies whether to let the system automatically find the optimum line speed for a call.
Maximum Transmit Bandwidth	Specifies the maximum transmit line speed between 64 kbps and the system's maximum line rate.
Maximum Receive Bandwidth	Specifies the maximum receive line speed between 64 kbps and the system's maximum line rate.

Configuring Dialing Preferences

Dialing preferences help you manage the network bandwidth used for calls. You can specify the default and optional call settings for outgoing calls. You can also limit the call speeds of incoming calls.

SVC-Based Conferencing

SVC-based conferences are not supported in this release of the RealPresence Immersive Studio system.

To specify dialing preferences:

- 1 Go to **Admin Settings > Network > Dialing Preference**.
- 2 Configure these settings.

Dialing Options and Preferred Speeds

Setting	Description
Scalable Video Coding Preference	AVC Only is supported in this release.
Enable H.239	Specifies standards-based People+Content data collaboration. Enable this option if you know that H.239 is supported by the far sites you will call.
Call Type Order	The default value is Video .

Dialing Options and Preferred Speeds

Setting	Description
Video Dialing Order	Specifies how the system places video calls to directory entries that have more than one type of number. It also specifies how the system places video calls when the call type selection is either unavailable or set to Auto . If a call attempt does not connect, the system tries to place the call using the next call type in the list.
Preferred Speed for Placed Calls: IP Calls	Determines the speed to use for calls from this system. If the far-site system does not support the selected speed, the system automatically negotiates a lower speed.
Maximum Speed for Received Calls: IP Calls	Enables you to restrict the bandwidth used when receiving IP calls. If the far site attempts to call the system at a higher speed than selected here, the call is renegotiated at the speed specified in this field.

Audio/Video Settings

Avoid changing the following settings unless advised by Polycom Technical Support.

Monitors

Do not change the default settings for the monitors.

Sleep

You can specify the period of inactivity before the system goes to sleep.

To configure when the system goes to sleep:

- 1 In the primary codec web UI, go to **Admin Settings > Audio/Video > Sleep**.
- 2 In the **Display** field, select Black.
- 3 In the **Time before system goes to sleep** field, select an option:
 - **Off**—The system will not go to sleep after a period of inactivity.
 - An idle period.
- 4 To mute the microphone while in sleep mode, enable the check box next to **Enable Mic Mute in Sleep Mode**.
- 5 Go to **Admin Settings > Audio/Video > Sleep**. If the **Display** field does not indicate No Signal, select **No Signal** from the drop down menu. Click **Save**.

Use Sleep Settings to Prevent Monitor Burn-In

Monitors used with Polycom RealPresence Immersive Studio systems provide display settings to help prevent image burn-in. The following guidelines help prevent image burn-in:

- Ensure that static images are not displayed for long periods.
- Set the **Time before system goes to sleep** to 60 minutes or less.

- To keep the screen clear of static images during a call, disable the following settings
 - **Show Time in Call (Admin Settings > General Settings > Date and Time > Time in Call)**
- Be aware that meetings that last more than an hour without much movement can have the same effect as a static image.

Video Inputs

To configure video input settings:

- 1 Go to **Admin Settings > Audio/Video > Video Inputs**.

Note the three tabs, labeled **Left**, **Main**, and **Right**, that control video input details for the left, main, and right systems.

- 2 If necessary, select a **Power Frequency** setting. The **Power Frequency** setting specifies the power line frequency for your system.

In most cases, the system defaults to the correct power line frequency, based on the video standard used in the country where the system is located. This setting enables you to adapt the system in areas where the power line frequency does not match the video standard used. You might need to change this setting to avoid flicker from the fluorescent lights in your conference room.

Audio

Avoid changing the following settings unless advised by Polycom Technical Support.

To configure the audio settings:

- 1 Go to **Admin Settings > Audio/Video > Audio**.
- 2 Configure the following settings.

General Audio Settings

Setting	Description
Sound Effects Volume	Sets the volume level of the ring tone and user alert tones.
Ringtone	Specifies the ring tone used for incoming calls.
User Alert Tones	Specifies the tone used for user alerts.
Mute Auto Answer Calls	Specifies whether to mute incoming calls. Incoming calls are muted by default until you press the mute button on the microphone or on the remote control.
Transmission Audio Gain (dB)	Specifies the audio level, in decibels, at which to transmit sound. Unless otherwise advised, Polycom suggests setting this value to 0 dB.

Audio Input Settings

Setting	Description
Type	Displays the type of input for connected components.
Audio Input Level	Sets the audio input level for each connection.

Audio Output Setting

Setting	Description
Master Audio Volume	Sets the main audio output volume level that goes to the speakers.

Security Settings

The security profile your RealPresence Immersive Studio system uses provides the basis for secure access within the system and determines how users can operate the system.

Security Profiles

This release of the RealPresence Immersive Studio system supports the **Low** security profile. You can customize some of the settings within this security profile as needed.

To view the security profile:

- 1 Go to **Admin Settings > Security > Global Security**.

- 2 Select the **Low** (default) security profile.

The **Low** security profile configures the system with no mandated security controls, although you can enable all controls as needed.

- 3 Select **Next**.

- 4 Follow the prompts in the **Security Profile Change** wizard.

Global Security

External Authentication

RealPresence Immersive Studio systems support two roles for accessing the system, an admin role and a user role. Admins can perform administrator activities such as changing configuration, as well as user activities such as placing and answering calls. Users can perform only user-type activities.

The systems provide two local accounts, one for the user role (by default named *user*) and one for the admin role (by default named *admin*). The IDs and passwords for these local accounts are stored on the RealPresence Immersive Studio system itself.

An administrator can configure the system to grant access using network accounts that are authenticated through an Active Directory (AD) server such as the Microsoft Active Directory server. In this case, the account information is stored on the AD server and not on the RealPresence Immersive Studio system. The AD administrator assigns accounts to AD groups, one for RealPresence Immersive Studio system *admin*

access and one for *user* access. For this reason, external authentication is also referred to as Active Directory authentication.

The RealPresence Immersive Studio system administrator configures the external authentication settings on the system to specify the address of an AD Server for authenticating user logins, AD group for user access, and AD group for admin access on the RealPresence Immersive Studio system. The system can map only one Active Directory group to a given role.



Note: External Authentication enabled in PKI environments

When External Authentication is enabled in PKI environments where Always Validate Peer Certificates from Server is enabled on the RealPresence Immersive Studio system, make sure to configure the Active Directory Server Address on the RealPresence Immersive Studio endpoint using the address information that is in the Active Directory Server's identity certificate. This is important in enabling the RealPresence Immersive Studio system to successfully validate the Active Directory Server's identity certificate.

As an example, if the Active Directory Server's identity certificate contains its DNS name only, and no specific IP address, configuring the Active Directory Server Address on the RealPresence Immersive Studio system using the server's IP address will result in certificate validation failure, and consequently authentication failure. The RealPresence Immersive Studio system configuration would have to specify the server by DNS name in this case to successfully match the server certificate data.

RealPresence Immersive Studio systems support Active Directory on Microsoft Windows Server version 2008 R2 and Microsoft Windows Server 2012.



Note: Enable Active Directory External Authentication

The RealPresence Immersive Studio system local user account is disabled when **Enable Active Directory External Authentication** is enabled. The admin account is active and usable, however.

To enable external authentication:

- 1 Go to **Admin Settings > Security > Global Security > Authentication**.
- 2 Configure these settings.

Authentication Settings

Setting	Description
Enable Active Directory External Authentication	Specifies whether to authenticate users through the Active Directory server. When Active Directory authentication is enabled, users are allowed to log in with their network account credentials, using this format: <i>domain\user</i> With this format, users can have accounts on multiple domains.
Active Directory Server Address	Specifies the DNS fully qualified domain name (FQDN) or IP address of the Active Directory server (ADS). If you are using subdomains, append port number 3268 as follows: <i>ad.domain.com:3268</i> Note: RealPresence Immersive Studio systems can use the RealPresence Resource Manager system as an ADS. If one is deployed in your environment, enter its address here. Otherwise, enter the address of an ADS.

Authentication Settings

Setting	Description
Active Directory Admin Group	Specifies the Active Directory group whose members should have admin access to the RealPresence Immersive Studio system. This name must exactly match the name in the ADS for authentication to succeed.
Active Directory User Group	Specifies the Active Directory group whose members should have user access to the RealPresence Immersive Studio system. This name must exactly match the name in the ADS for authentication to succeed.

**Note: If external authentication is not active**

If external authentication is not active after completing these steps, go to **Admin Settings > Network > LAN Properties > LAN Options** and ensure that the **Domain Name** setting contains the name of your Active Directory domain.

Access

Settings in this section enable you to configure remote usage of the RealPresence Immersive Studio system, such as by using the web, a serial port, or Telnet. A *session* is an instance of a user connected to the system through one of these interfaces. Sessions include an indication of how you are logged on to the RealPresence Immersive Studio system, such as the local interface, web interface, Telnet, or serial API.

To configure access settings:

- 1 Go to **Admin Settings > Security > Global Security > Access**.
- 2 Configure the following settings. Your security profile might affect the availability of some settings.

Access Settings

Setting	Description
Enable Network Intrusion Detection System (NIDS)	Activates the ability to log entries to the security log when the system detects a possible network intrusion. This setting is enabled or disabled by default based on the security profile, but can be changed.
Enable Web Access	Specifies whether to allow remote access to the system by using the web interface.
Allow Access to User Settings	Specifies whether the User Settings screen is accessible to users through the local interface.
Restrict to HTTPS	Specifies that the web server is accessible only over a secure HTTPS port. Enabling this setting closes the HTTP port and so disables redirects of sessions from HTTP to HTTPS (all access must be initiated as HTTPS).

Access Settings

Setting	Description
Web Access Port (HTTP)	Specifies the port to use when accessing the system using the Polycom RealPresence Immersive Studio system web interface using HTTP. If you change this from the default (port 80), specify a port number of 1025 or higher, and make sure the port is not already in use. You will need to include the port number with the IP address when you use the Polycom RealPresence Immersive Studio system web interface to access the system. This makes unauthorized access more difficult. If Restrict to HTTPS is enabled, the Web Access Port setting is unavailable.
Enable Telnet Access	Specifies whether to allow remote access to the system by Telnet.
Enable SNMP Access	Not supported.
API Port	Specifies the port for API access. Select port 23 or 24. If you set the API port to port 23, the diagnostics port changes to port 24.
Lock Port after Failed Logins	For information about this setting, refer to Account Lockout .
Enable SSH Access	Specifies whether to allow SSH access.
Enable Diagnostics Port Idle Session Timeout	Specifies whether to allow the diagnostics port to time out at the configured time interval or not. The timeout setting is set under Idle Session Timeout in Minutes .
Enable API Port Idle Session Timeout	Specifies whether to allow the API port to time out at the configured time interval or not. The timeout setting is set under Idle Session Timeout in Minutes .
Enable SNMP Access	Specifies whether to allow remote access to the system by SNMP.
Enable Whitelist	Specifies whether the system web interface ports accept connections only from specified IP addresses.
Idle Session Timeout in Minutes	Specifies the number of minutes your web interface session can be idle before the session times out.
Maximum Number of Active Sessions	Specifies the maximum number of users who can be logged in to and using your system through Telnet or the web interface at the same time.

Encryption Settings

AES encryption is a standard feature on all Polycom RealPresence Immersive Studio systems. When it is enabled, the system automatically encrypts calls to other systems that have AES encryption enabled.

If encryption is enabled on the system, a locked padlock icon appears on the monitor when a call is encrypted. If a call is unencrypted, an unlocked padlock appears on the monitor. In a multipoint call, some connections might be encrypted while others are not. The padlock icon might not accurately indicate whether the call is encrypted if the call is cascaded or includes an audio-only endpoint. To avoid security risks, Polycom recommends that all participants communicate the state of their padlock icon verbally at the beginning of a call.

RealPresence Immersive Studio systems provide the following AES cryptographic algorithms to ensure flexibility when negotiating secure media transport:

- H.323 (per H.235.6)
 - AES-CBC-128 / DH-1024
 - AES-CBC-256 / DH-2048
- SIP (per RFCs 3711, 4568, 6188)
 - AES_CM_128_HMAC_SHA1_32
 - AES_CM_128_HMAC_SHA1_80
 - AES_CM_256_HMAC_SHA1_32
 - AES_CM_256_HMAC_SHA1_80

RealPresence Immersive Studio systems also support the use of FIPS 140 validated cryptography, which is required in some instances, such as when used by the U.S. federal government. When the **Require FIPS 140 Cryptography** setting is enabled, all cryptography used on the system comes from a software module that has been validated to FIPS 140-2 standards. You can find its FIPS 140-2 validation certificate here: <http://csrc.nist.gov/groups/STM/cmvp/documents/140-1/140val-all.htm#1747>.

To enable encryption:

- 1 Go to **Admin Settings > Security > Global Security > Encryption**.
- 2 Configure these settings.

Encryption Settings

Setting	Description
Require AES Encryption for Calls AES Encryption in local interface	<p>Specifies how to encrypt calls with other sites that support AES encryption.</p> <ul style="list-style-type: none"> • Off—AES Encryption is disabled. • When Available—AES Encryption is used with any endpoint that supports it, even if the other endpoints in the call do not support it. • Required for Video Calls Only—AES Encryption is used for all video endpoints in the call. Video endpoints must support AES Encryption to participate in the call. • Required for All Calls—AES Encryption is used for all video endpoints in the call. All endpoints must support AES Encryption to participate in the call.
Require FIPS 140 Cryptography	<p>Enables the exclusive use of the FIPS 140-2-validated software cryptography module for cryptographic functions. Also disables all “weak” protocols and ciphers, including:</p> <ul style="list-style-type: none"> • SSLv2 • SSLv3 • Non-FIPS 140-2 approved TLS cipher suites

Local Account Settings

Account Lockout

RealPresence Immersive Studio systems provide access controls that prevent unauthorized use of the system. One way someone might try to discover valid user names and passwords is by exhaustively attempting to log in, varying the user name and password data in a programmatic way until discovering a combination that succeeds. Such a method is called a “brute-force” attack.

To mitigate the risk of such an attack, two access control mechanisms are available on RealPresence Immersive Studio systems. The first type of access control, account lockout, protects local accounts from being vulnerable to brute-force attacks, while the second, port lockout, protects login ports themselves from being vulnerable to brute-force attacks.

Account lockout temporarily locks a local account from accepting logins after a configurable number of unsuccessful attempts to log in to that account. It protects only the local RealPresence Immersive Studio system’s Admin and User local accounts. When external authentication is used, the Active Directory Server protects Active Directory accounts.

RealPresence Immersive Studio systems provide separate account lockout controls for each of their local accounts, which are named **Admin** and **User**. The account lock can be invoked due to failed logins on any of the following login ports:

- Local interface
- Web interface
- Telnet interface

To configure the account lockout feature:

- 1 Go to **Admin Settings > Security > Local Accounts > Account Lockout**.
- 2 Configure these settings for the appropriate account on the Account Lockout page. You can configure account lock for the admin account, user account, or both accounts.

Account Lockout Settings

Setting	Description
Lock Admin/User Account after Failed Logins	Specifies the number of failed login attempts allowed before the system locks the account. If set to Off , the system does not lock the user account due to failed login attempts.
Admin/User Account Lock Duration	Specifies the amount of time that the account remains locked due to failed login attempts. After this time period has expired, the failed login attempts counter is reset to zero and logins to the account are once again allowed.

The following are examples of how the account lockout feature works.

A RealPresence Immersive Studio system web interface is configured with these settings:

- **Admin Settings > Security > Local Accounts > Account Lockout > Lock Admin Account after Failed Logins** is set to **4**.
- **Admin Settings > Security > Local Accounts > Account Lockout > Admin Account Lock Duration** is set to **1 Minute**.

- **Admin Settings > Security > Local Accounts > Account Lockout > Reset Admin Account Lock After** is set to **1 Hour**.

Scenario 1 - Admin account locked due to excessive failed logins

A user fails to log in to the **Admin** account three times on the web interface. If the next attempt to log in to the **Admin** account on any login port is unsuccessful, which would mean **4** failed logins, further attempts to access the **Admin** account are locked out for **1 Minute** (the expiration of the **Admin Account Lock Duration** period). After the **1 Minute** account lock duration has past, logins will once again be allowed. As this example illustrates, the failed login attempts made to an account accumulate across any login port.

Scenario 2 - Successful login resets the failed login attempts counter

A user fails to log in to the **Admin** account three times on the web interface. If the next login attempt is successful, then the failed login attempts counter for the **Admin** account is reset to zero and now once again 4 failed attempts can be made before the **Admin** account would be locked.

Scenario 3 - Failed attempts counter resets after failed login window closes

A user fails to log in to the **Admin** account three times on the web interface. If no more failed attempts are made within **1 Hour** of the first failed attempt (which is the value of the **Reset Admin Account Lock Counter After** setting), the failed login attempts counter for the **Admin** account is reset to zero, and 4 failed attempts are allowed again before the **Admin** account is locked.

Login and Credentials

To configure local access to the system:

- 1 Go to **Admin Settings > Security > Local Accounts > Login Credentials**.
- 2 Configure the following settings for each system in your RealPresence Immersive Studio setup.

Login Credentials

Setting	Description
Admin ID	Specifies the ID for the administrator account. The default Admin ID is <code>admin</code> . Admin IDs are not case sensitive.
Admin Room Password	Specifies the password for the local administrator account used when logging in to the system locally. When this password is set, you must enter it to configure the system Admin Settings using the remote control. The password cannot contain spaces or be more than 40 characters. Passwords are case sensitive. The default Admin Room Password is the 14-digit system serial number from the System Information screen or the back of the system.
Use Room Password for Remote Access	Specifies whether the room password used for local login is also used for the remote login. When this setting is disabled, the remote access password settings are displayed.
Admin Remote Access Password	Specifies the password for the local administrator account used when logging in to the system remotely using the web interface or a telnet session. When this password is set, you must enter it to update the software or manage the system from a computer. The password cannot contain spaces or more than 40 characters.

Login Credentials

Setting	Description
Require User Login for System Access	Not Supported
User ID	Not Supported
User Room Password	Not Supported
User Remote Access Password	Not Supported

Password Requirements

You can configure password policies for Admin, User, Meeting, and Remote Access passwords. These password settings can ensure that strong passwords are used. Polycom strongly recommends that you create an Admin password for your system.

To configure password requirements:

- 1 Go to **Admin Settings > Security > Local Accounts > Password Requirements**.
- 2 Configure the following settings.

Password Policy Settings

Setting	Description
Minimum Length	Specifies the minimum number of characters required for a valid password.
Require Lowercase Letters	Specifies whether a valid password must contain one or more lowercase letters.
Require Uppercase Letters	Specifies whether a valid password must contain one or more uppercase letters.
Require Numbers	Specifies whether a valid password must contain one or more numbers.
Require Special Characters	Specifies whether a valid password must contain one or more special characters. Supported characters include: @ - _ ! ; \$, \ / & . # *
Reject Previous Passwords	Specifies the number of most recent passwords that cannot be reused. If set to Off , all previous passwords can be reused.
Minimum Password Age in Days	Specifies the minimum number of days that must pass before the password can be changed.
Maximum Password Age in Days	Specifies the maximum number of days that can pass before the password must be changed. Note: This setting is unavailable for Meeting passwords.
Minimum Changed Characters	Specifies the number of characters that must be different or change position in a new password. If this is set to 3 , 123abc can change to 345cde but not to 234bcd. Note: This setting is unavailable for Meeting passwords.

Password Policy Settings

Setting	Description
Maximum Consecutive Repeated Characters	Specifies the maximum number of consecutive repeated characters in a valid password. If this is set to 3 , <code>aaa123</code> is a valid password but <code>aaaa123</code> is not.
Password Expiration Warning	Specifies how many days in advance the system displays a warning that the password will soon expire, if a maximum password age is set. Note: This setting is unavailable for Meeting passwords.
Can Contain ID or Its Reverse Form	Specifies whether the associated ID or the reverse of the ID can be part of a valid password. If this setting is enabled and the ID is <code>admin</code> , passwords <code>admin</code> and <code>nimda</code> are allowed. Note: This setting is unavailable for Meeting passwords.

Changes to most password policy settings do not take effect until the next time the password is changed. Changes take effect immediately for **Minimum Password Age in Days**, **Maximum Password Age in Days**, and **Password Expiration Warning**. Changing **Minimum Length** from **Off** to some other value also takes effect immediately.

Manage Certificates and Revocation

If your organization has deployed a public key infrastructure (PKI) for securing connections between devices on your network, Polycom recommends that you have a strong understanding of certificate management and how it applies to Polycom RealPresence Immersive Studio before you integrate this system with the PKI.

The RealPresence Immersive Studio system can use certificates to authenticate network connections to and from the Polycom RealPresence Immersive Studio system. Other web applications also use certificates, as you might notice when you navigate the Internet. The system uses configuration and management techniques typical of PKI to manage certificates, certificate signing requests, and revocation checking. ANSI X.509 standards regulate the characteristics of certificates and revocation.

Polycom RealPresence Immersive Studio systems can generate requests for certificates (CSRs) that can be sent to a certificate authority (CA) for official issuance. The CA is the trusted entity that issues, or signs, digital certificates for others. After being signed by the CA, you can install the certificate on the RealPresence Immersive Studio system for use in all TLS connections used by the system.

RealPresence Immersive Studio systems support, and typically require, the generation and use of two separate certificates when used in an environment that has a fully deployed PKI:

- A Server certificate—the RealPresence Immersive Studio system's web server presents this certificate after receiving connection requests from browsers attempting to connect to the RealPresence Immersive Studio system web interface.
- A Client certificate—the RealPresence Immersive Studio system presents this certificate to a remote server when challenged to provide a certificate as part of authenticating the identity of the RealPresence Immersive Studio system before enabling it to connect to the remote server. Examples of remote servers include the RealPresence Resource Manager system, a SIP proxy/registrar server, or an LDAP directory server.

When RealPresence Immersive Studio systems are deployed in an environment that does not have a fully deployed PKI, you do not need to install these certificates because all RealPresence Immersive Studio systems automatically generate *self-signed* certificates that can be used to establish secure TLS

connections. However, when a full PKI has been deployed, self-signed certificates are not trusted by the PKI; therefore signed certificates must be used. The following sections describe how to generate and use certificates by using the Polycom RealPresence Immersive Studio system web interface.

Generate Certificate Signing Requests (CSRs)

The RealPresence Immersive Studio system enables you to install one client and one server certificate for identification of the RealPresence Immersive Studio system to network peers. In order to obtain these certificates you must first generate a Certificate Signing Request (CSR) for each certificate. This request, also known as an *unsigned certificate*, must be submitted to a CA so that it can be signed, after which the certificate can be installed on the RealPresence Immersive Studio system. Whether you need to generate a client-type CSR, a server-type CSR, or both depends on which features and services you intend to use, and whether your network environment supports certificate-based authentication for those services. In most cases, both certificates are needed.

For example, if your RealPresence Immersive Studio system is configured to use any of the following features, and the servers providing those services perform certificate-based authentication before allowing access to them, you must create a client-type CSR and add the resulting certificate signed by the CA:

- RealPresence Resource Manager system Provisioning
- RealPresence Resource Manager system Monitoring
- RealPresence Resource Manager system LDAP Directory
- RealPresence Resource Manager system Presence
- Calendaring
- SIP
- 802.1X

The RealPresence Immersive Studio system web server uses the server-type CSR and resulting certificate whenever an administrator attempts to connect to the RealPresence Immersive Studio system web interface. The web server does so by presenting the server certificate to the browser to identify the system to the browser as part of enabling the browser to connect to the system. The browser's user needs the server certificate if he or she wants to be certain about the identity of the RealPresence Immersive Studio system he or she is connecting to. Settings in the web browser typically control the validation of the server certificate, but you can also validate the certificate manually.

To obtain a client or server certificate, you must first create a CSR. You can create one client and one server CSR and submit each to the appropriate CA for signing. After the CSR is signed by a CA, it becomes a certificate you can add to the RealPresence Immersive Studio system.

To create a CSR:

- 1 Go to **Admin Settings > Security > Certificates > Certificate Options**.
- 2 Click **Create** for the type of CSR you want to create, **Signing Request Server** or **Signing Request Client**. The procedure is the same for server and client CSRs.
- 3 Configure these settings on the Create Signing Request page, and click **Create**.

Setting	Description
Hash Algorithm	Specifies the hash algorithm for the CSR. You may select SHA-256 or keep the default SHA-1.
Common Name (CN)	Specifies the name that the system assigns to the CSR. Polycom recommends the following guidelines for configuring the Common Name: <ul style="list-style-type: none"> For systems registered in DNS, use the Fully Qualified Domain Name (FQDN) of the system. For systems not registered in DNS, use the IP address of the system.
Organizational Unit (OU)	Specifies the unit of business defined by your organization.
Organization (O)	Specifies your organization's name.
City or Locality (L)	Specifies the city where your organization is located.
State or Province (ST)	Specifies the state or province where your organization is located.
Country (C)	Displays the country selected in Admin Settings > General Settings > My Information .



Note: The RealPresence Immersive Studio system supports only one OU field.

If you want the signed certificate to include more than one OU field, download and edit the CSR manually.

After you create the CSR, the system displays a message indicating that the CSR has been created. Two links appear next to the signing request that you just created (**Signing Request Server** or **Signing Request Client**).

- **Download Signing Request** enables you to download the CSR so that it can be sent to a CA for signature.
- **Create** enables you to view the fields of the CSR as they are currently set in the CSR. If you change any of the values you previously configured, you can click **Create** to generate a new CSR that can then be downloaded.



Note: Only a single outstanding CSR of either type can exist at a time.

After the CSR is generated, it is important to get it signed and installed before attempting to generate a different CSR of the same type.

For example, if you generate a client CSR and then, prior to having it signed and installed on the RealPresence Immersive Studio system, another client CSR is generated, the previous CSR is discarded and invalidated, and any attempt to install a signed version of it will result in an error.

Install Certificates

After you have downloaded a CSR and it has been signed by a CA, the resulting certificate is ready to install on the RealPresence Immersive Studio system. The following section outlines how to do this. The procedure is the same for installing the client certificate, the server certificate, and any required CA-type certificates.

To add a signed certificate on the Certificates page:

- 1 Click **View and Add** to open the certificate section.
- 2 Next to **Add Certificate**, click **Browse** to search for and select a certificate. You might be installing a client or server certificate that has been signed by a CA after having been previously generated as a CSR, or installing a CA certificate needed by the RealPresence Immersive Studio system to validate a certificate it receives from another system.
- 3 Click **Open**.
The system checks the certificate data and adds it to the list. If you don't see the certificate in the list, the system was unable to recognize the certificate. This process is sometimes referred to as *installing* a certificate.
You can select a certificate in the list to view its contents. You can also remove a certificate from the list by clicking **Remove**.
- 4 If needed, click **Close** to close the certificate section of the page.
- 5 Click **Save**.

When you add a CA certificate to the RealPresence Immersive Studio system, the certificate becomes trusted for the purpose of validating peer certificates.



Note: Security certificate error message

If you do not add the server certificate for the RealPresence Immersive Studio system before using the web interface, you might receive error messages from your browser stating that the security certificate for the web site "Polycom" cannot be verified. Most browsers allow the user to proceed after this warning is displayed. See the Help section of your browser for instructions on how to do this.

Configure Certificate Validation Settings

Certificates are authorized externally when they are signed by the CA. The certificates can be automatically validated when they are used to establish an authenticated network connection. To perform this validation, the RealPresence Immersive Studio system must have certificates installed for all CAs that are part of the *trust chain*. A trust chain is the hierarchy of CAs that have issued certificates from the device being authenticated, through the intermediate CAs that have issued certificates to the various CAs, leading back to a *root CA*, which is a known trusted CA. The following sections describe how to install and manage these certificates.

A certificate exchange is between a server and a client, both of which are peers. When a user is accessing the RealPresence Immersive Studio system web interface, the RealPresence Immersive Studio system is the server and the web browser is the client application. In other situations, such as when the RealPresence Immersive Studio system connects to LDAP directory services, the RealPresence Immersive Studio system is the client and the LDAP directory server is the server.

To configure certificate usage:

- 1 Go to **Admin Settings > Security > Certificates > Certificate Options**.
- 2 Configure these settings on the Certificates screen and click **Save**.

Setting	Description
Maximum Peer Certificate Chain Depth	Specifies how many links a certificate chain can have. The term <i>peer certificate</i> refers to any certificate sent by the far-end host to the RealPresence Immersive Studio system when a network connection is being established between the two systems.
Always Validate Peer Certificates from Browser	Not supported.
Always Validate Peer Certificates from Server	Controls whether the RealPresence Immersive Studio system requires the remote server to present a valid certificate when connecting to it for services such as those listed for client-type CSRs in Generate Certificate Signing Requests (CSRs) (provisioning, directory, SIP, and so forth).

Configure Certificate Revocation Settings

When certificate validation is enabled, the RealPresence Immersive Studio system tries to validate the peer certificate chain on secure connection attempts for the applicable network services.

Part of the validation process includes a step called *revocation checking*. This type of check involves consulting with the CA that issued the certificate in question to see whether the certificate is still active or has been revoked for some reason. Revoked certificates are considered invalid because they might have been compromised in some way or improperly issued, or for other similar reasons. The CA is responsible for maintaining the revocation status of every certificate that it issues. The RealPresence Immersive Studio system can check this revocation status by using either of the following methods:

- Certificate revocation lists (CRLs). A CRL is a list of certificates that have been revoked by the CA. A CRL must be installed on the RealPresence Immersive Studio system for each CA whose certificate has been installed on the system.
- The Online Certificate Status Protocol (OCSP). OCSP allows the RealPresence Immersive Studio system to contact an *OCSP responder*, which is a network server that provides real-time certificate status through a query/response message exchange.

You must configure the RealPresence Immersive Studio system to use the revocation method most appropriate for your environment.

To use Certificate Revocation Lists (CRLs):

- 1 Go to **Admin Settings > Security > Certificates > Revocation**.
- 2 Configure these settings on the Revocation page, and click **Save**.

Setting	Description
Revocation Method	Select the CRL method.

Setting	Description
Allow Incomplete Revocation Checks	When this field is enabled, a certificate in the chain is verified without a revocation status check if no corresponding CRL for the issuing CA is installed. The RealPresence Immersive Studio system assumes that the lack of a CRL means the certificate is not revoked. If a CRL is installed, the system performs a revocation check when validating the certificate.
Add CRL	<ol style="list-style-type: none"> 1 Click Browse to search for and select a CRL. 2 Click Open to add the CRL to the list.

You can also view automatically and manually downloaded CRLs on this page. To remove a CRL from the list, click **Remove**.



Note: CRLs available for retrieval by HTTP

The RealPresence Immersive Studio systems automatically download CRLs from the Certificate Authorities (CAs) that make CRLs available for retrieval by HTTP.

However, for CAs that do not allow HTTP retrieval of CRLs, the RealPresence Immersive Studio system administrator is responsible for manually installing and updating CRLs ahead of their expiration. It is extremely important that CRLs be kept up to date.



Note: Always Validate Peer Certificates from Browsers setting

If the **Always Validate Peer Certificates from Browsers** setting is enabled and the expired CRL is for a CA that is part of the trust chain for the client certificate sent by your browser, you will no longer be able to connect to the RealPresence Immersive Studio system web interface because the revocation check will always fail. In this case, unless the RealPresence Immersive Studio system web interface can be accessed by a user whose client certificate's trust chain does not include the CA whose CRL is expired, you must delete all certificates and CRLs from the system and then reinstall them. See the [RealPresence Server Address Configuration in PKI-Enabled Environments](#) for more information.

To use Online Certificate Status Protocol (OCSP):

- 1 Go to **Admin Settings > Security > Certificates > Revocation**.
- 2 Configure these settings on the Revocation page and click **Save**.

Setting	Description
Revocation Method	Select the OSCP method.
Allow Incomplete Revocation Checks	<p>When this field is enabled, the RealPresence Immersive Studio system treats the following response from the OCSP responder as a successful revocation checks that would otherwise be considered a failed check:</p> <ul style="list-style-type: none"> If the OCSP responder responds that the status is <i>unknown</i> or if no response is received, the system treats this as a successful revocation check. <p>Regardless of the state of this setting, the following statements apply:</p> <ul style="list-style-type: none"> If the OCSP responder indicates a known <i>revoked</i> status, the RealPresence Immersive Studio system treats this as a revocation check failure and does not allow the connection. If the OCSP responder indicates a known <i>good</i> status, the RealPresence Immersive Studio system treats this as a successful revocation check and allows the connection.
Global Responder Address	Specifies the URI of the responder that services OCSP requests (for example, <code>http://responder.example.com/ocsp</code>). This responder is used for all OCSP validation when Use Responder Specified in Certificate is disabled, and is sometimes used even when Use Responder Specified in Certificate is enabled. Polycom therefore recommends that you always enter a Global Responder Address regardless of the value chosen for the Use Responder Specified in Certificate setting.
Use Responder Specified in Certificate	<p>In some cases, the certificate itself includes the responder address. When this field is enabled, the RealPresence Immersive Studio system attempts to use the address in the certificate (when present) instead of the Global Responder Address specified in the previous field.</p> <p>Note: The Polycom RealPresence Immersive Studio system supports only the use of HTTP URLs in the AIA field of a certificate when Use Responder Specified in Certificate is enabled.</p>

**Note: OCSP**

If you use OCSP, you might need to install one or more additional CA certificates on the RealPresence Immersive Studio system, for validation of the OCSP response messages.

Certificates and Security Profiles within a Provisioned System

When your RealPresence Immersive Studio system is provisioned through the RealPresence Resource Manager system and you use PKI certificates, consider the following information. Be sure to enable provisioning **after** you follow the procedures applicable to each Security Profile type.

To use the Low Security Profile with provisioning:

- » The RealPresence Resource Manager system must be using commercial mode.
- » You can enable provisioning in the setup wizard. All provisionable settings are taken from the RealPresence Resource Manager system.

RealPresence Server Address Configuration in PKI-Enabled Environments

When configuring the server addresses for the services listed in [Generate Certificate Signing Requests \(CSRs\)](#) as potentially needing a client-type CSR (such as SIP or LDAP directory), you might need to use a particular address format if the server address is contained in the server certificate that it presents when connecting to it. If this is the case, use the following guidance for configuring these server addresses on the RealPresence Immersive Studio system:

- If the certificate contains the fully qualified domain name (FQDN) of the server, use the FQDN when configuring the server address.
- If the certificate contains the IP address of the server, use the IP address when configuring the server address.
- If the certificate does not contain any the server's address in any form, you can use either the FQDN or the IP address of the server when configuring the server address.

Security Banners

Security banners are not supported.

Log Management

The RealPresence Immersive Studio system log files comprise the following information:

- System logs
- Call Detail Report (CDR)
- Configuration profile

You can download logs by using the Polycom RealPresence Immersive Studio system web interface. The date and time of system log entries for RealPresence Immersive Studio systems are shown in GMT.

When the log fills up past the threshold, the following actions are triggered:

- Transfers the log to the USB device if Transfer Frequency is set to “Auto at Threshold”
- Creates a log entry indicating that the threshold has been reached
- Displays an alert on the home screen
- Displays an indicator on the System Status screen

To view the log file status:

- 1 Go to **Diagnostics > System > System Status**.
- 2 Select the **More Info** link for **Log Threshold** for each system in your RealPresence Immersive Studio setup.



Note: Log Threshold system status

When the Log Threshold system status indicator is red, automatic log transfers cannot be completed and data can be lost.

To configure log management:

- 1 Go to **Admin Settings > Security > Log Management**.
- 2 Configure these settings.

Log Management Settings

Setting	Description
Current Percent Filled	Displays how full the log file is as a percentage of the total size.
Percent Filled Threshold	Specifies a threshold for the percent filled value. Reaching the threshold triggers an alarm, creates a log entry, and transfers the log if Transfer Frequency is set to Auto at Threshold . Off disables logging threshold notifications.
Folder Name	Specifies the name to give the folder for log transfers. System Name and Timestamp — Folder name is the system name and the timestamp of the log transfer, in the date and time format specified on the Location screen. For example, if the system name is “Marketing”, the folder name could be marketing_MMddyyyymmssSSS. Timestamp — Folder name is the timestamp of the log transfer, in the date and time format specified on the Location screen, for example yyyyMMddhhmmssSSS. Custom — Optional folder name for manual log transfers.
Storage Type	Specifies the type of storage device used for log file transfers.
Transfer Frequency	Specifies when the logs are transferred: Manual — The transfer starts when you select the Start Log Transfer button, which is visible only on the local interface. If the log fills before being transferred, new events overwrite the oldest events. Auto at Threshold — The transfer starts automatically when the Percent Filled Threshold is reached.

Configure Servers

This section shows how to set up various servers in your RealPresence Immersive Studio system.

Set Up a Directory Server

The global directory provides a list of other systems that are registered with the Global Directory Server and available for calls. The other systems appear in the directory, enabling users to place calls to other users by selecting their names.

You can configure the system to use one of the following directory servers in standard operating mode.

Directory Servers Supported in Standard Operating Mode

Directory Servers Supported	Authentication Protocols	Global Directory Groups	Entry Calling Information
LDAP with H.350 or Active Directory	Any of the following: <ul style="list-style-type: none"> • NTLM v2 only • Basic • Anonymous 	Not Supported	Might include: <ul style="list-style-type: none"> • H.323 IP address (raw IPv4 address, DNS name, H.323 dialed digits, H.323 ID, or H.323 extension) • SIP address (SIP URI) • ISDN number • Phone number *
Microsoft Lync Server 2013 and Skype for Business Server 2015	NTLM v2 only	Contact groups but not distribution lists	Might include SIP address (SIP URI)

* To successfully call a phone number from the LDAP directory, the phone number must be stored in one of the following formats:

- +Country Code.Area Code.Number
- +Country Code.(National Direct Dial Prefix).Area Code.Number

You can configure the system to use the following directory servers when the system is automatically provisioned by a Polycom RealPresence Resource Manager system.

Directory Servers Supported by Polycom RealPresence Resource Manager Provisioning

Directory Servers Supported	Authentication Protocol	Global Directory Groups	Entry Calling Information
LDAP by a Polycom RealPresence Resource Manager system	NTLM v2 only	Pre-defined groups from the LDAP directory are shown in Polycom RealPresence Immersive Studio system's directory	Might include: <ul style="list-style-type: none"> • H.323 dialed digits, H.323 ID, or H.323 extension • Phone number * • SIP address
Microsoft Lync Server 2013 and Skype for Business Server 2015	NTLM v1 only	Contact groups but not distribution lists	Might include SIP address (SIP URI)

* To successfully call a phone number from the LDAP directory, the phone number must be stored in one of the following formats:

- +Country Code.Area Code.Number
- +Country Code.(National Direct Dial Prefix).Area Code.Number

To configure the LDAP directory server:

- 1 Go to **Admin Settings > Servers > Directory Servers** and select the **LDAP Server Type**.
- 2 Configure these settings.

LDAP Server Settings

LDAP Setting	Description
Server Address	Specifies the address of the LDAP directory server. With Automatic Provisioning, this setting is configured by the server and appears as read only.
Server Port	Specifies the port used to connect to the LDAP server. With Automatic Provisioning, this setting is configured by the server and appears as read only.
Base DN (Distinguished Name)	Specifies the top level of the LDAP directory where searches will begin. With Automatic Provisioning, this setting is configured by the server and appears as read only.
Authentication Type	Specifies the protocol used for authentication with the LDAP server: NTLM, BASIC, or Anonymous.
Use SSL (Secure Socket Layer)	Enables SSL for securing data flow to and from the LDAP server.
Bind DN (Distinguished Name)	The user ID of the person allowed to search the LDAP directory, which must be in a standard DN format such as cn=user, dc=example, dc=com.
Domain Name	Specifies the domain name for authentication with the LDAP server.
User Name	Specifies the user name for authentication with LDAP server.
Password	Specifies the password for authentication with the LDAP server.

To configure the Microsoft Lync Server 2013 and Skype for Business Server 2015 directory settings:

- 1 Go to **Admin Settings > Network > IP > SIP Settings**.
- 2 Configure the SIP settings as described in [SIP Settings](#).
- 3 Go to **Admin Settings > Servers > Directory Servers** and select **Microsoft** for the **Server Type**.
- 4 Configure these settings.

Microsoft Directory Server Settings

Setting	Description
Registration Status	Specifies whether the system is successfully registered with the Microsoft Lync Server.
Domain Name	Specifies the Domain Name entered on the SIP Settings screen.
Domain User Name	Specifies the Domain User Name entered on the SIP Settings screen.
User Name	Specifies the User Name entered on the SIP Settings screen.

Use a Provisioning Service

If your organization uses the Polycom RealPresence Resource Manager system, you can manage Polycom RealPresence Immersive Studio systems in dynamic management mode. In dynamic management mode, the following might be true:

- Polycom RealPresence Immersive Studio systems are registered to a standards-based presence service, so presence states are shared with Contacts.
- Polycom RealPresence Immersive Studio systems have access to a corporate directory that supports LDAP access.
- The Domain, User Name, Password, and Server Address fields are populated on the Provisioning Service screen.
- Configuration settings that are provisioned, or that are dependent on provisioned values, are read-only on the RealPresence Immersive Studio system.
- The Polycom RealPresence Immersive Studio system checks for new software from the Polycom RealPresence Resource Manager system every time it restarts and at an interval set by the service. It automatically accesses and runs any software updates made available by the Polycom RealPresence Resource Manager system.
- A RealPresence Resource Manager system administrator can upload a provisioned bundle from an already configured RealPresence Immersive Studio system. When RealPresence Immersive Studio systems request provisioning, the provisioned bundle and any automatic settings are downloaded. A RealPresence Immersive Studio system user with administrative rights can change the settings on the RealPresence Immersive Studio system after the provisioned bundle is applied. If you later download a new provisioned bundle from the RealPresence Resource Manager system, the new bundle overwrites the manual settings.
- If the system has previously registered successfully with a provisioning service but fails to detect the service when it restarts or checks for updates, an alert appears on the System Status screen. If the system loses registration with the provisioning service, it continues operating with the most recent configuration that it received from the provisioning service.

Enable or Disable the Provisioning Service

To register the Polycom RealPresence Immersive Studio system with the Polycom RealPresence Resource Manager system, enter the registration information and attempt to register by going to **Admin Settings** in the Polycom RealPresence Immersive Studio system web interface.

To enable a provisioning service:

- 1 Go to **Admin Settings > Servers > Provisioning Service**.
- 2 Select the **Enable Provisioning** setting.
- 3 Enter the **Domain**, **User Name**, **Password**, and **Server Address** for automatic provisioning. Multiple Polycom RealPresence Immersive Studio systems can be registered to a single user.
- 4 Select **Register or Update**. The system tries to register with the Polycom RealPresence Resource Manager system using NTLM authentication.

To disable a provisioning service:

- 1 Go to **Admin Settings > Servers > Provisioning Service**.
- 2 Disable the **Enable Provisioning** setting.

Provisioning Service Settings

If automatic provisioning is enabled but the system does not register successfully with the provisioning service, you might need to change the **Domain**, **User Name**, **Password**, or **Server Address** used for registration. For example, users might be required to periodically reset passwords used to log into the

network from a computer. If such a network password is also used as the provisioning service password, you must update it on the Polycom RealPresence Immersive Studio system, too.

To avoid unintentionally locking a user out of network access in this case, RealPresence Immersive Studio systems will not automatically retry registration until you update the settings and register manually on the Provisioning Service page.

To configure the provisioning service settings:

- 1 Go to **Admin Settings > Servers > Provisioning Service**.
- 2 Configure these settings.

Provisioning Service Settings

Setting	Description
Domain	Specifies the domain for registering to the provisioning service.
User Name	Specifies the endpoint's user name for registering to the provisioning service.
Password	Specifies the password that registers the system to the provisioning service.
Server Address	Specifies the address of the Polycom RealPresence Resource Manager system running the provisioning service.

Connect to the Microsoft Exchange Server Calendaring Service

Polycom RealPresence Immersive Studio systems can connect to Microsoft Exchange Server 2010 or 2013 and retrieve calendar information. Connecting to a calendaring service enables the system to:

- Display the day's scheduled meetings, along with details about each.
- Hide or show details about meetings marked Private, depending on the configuration of the system.
- Display a meeting reminder before each scheduled meeting, along with a reminder tone.

To configure Calendaring properties:

- 1 Go to **Admin Settings > Servers > Calendaring Service**.
- 2 Configure these settings.

Calendaring Settings

Setting	Description
Enable Calendaring Service	Enables the system to connect to the Microsoft Exchange Server 2010 or 2013 or and retrieve calendar information.
Microsoft Exchange Server	Specifies the Fully Qualified Domain Name (FQDN) of the Microsoft Exchange Client Access Server. If your organization has multiple Client Access Servers behind a network load balancer, this is the FQDN of the server's Virtual IP Address. If required, an IP address can be used instead of an FQDN, but Polycom recommends using the same FQDN that is used for Outlook clients.
Secure Connection Protocol	Specifies the secure connection protocol.

Calendaring Settings

Setting	Description
Domain	Specifies the domain for registering to the Microsoft Exchange Server 2010 or 2013, in either NETBIOS or DNS notation, for example, either company.local or COMPANY.
User Name	Specifies the user name for registering to the Microsoft Exchange Server 2010 or 2013, with no domain information included. This can be the system's name or an individual's name.
Password	Specifies the system's password for registering with the Microsoft Exchange Server 2010 or 2013.
Email	Specifies the Outlook mailbox this system should monitor for calendar information. This should match the Primary SMTP Address for the account in Microsoft Exchange Server 2010 or 2013, which is displayed as the value of the mail attribute in the account properties.
Meeting Reminder Time In Minutes	Specifies the number of minutes before a meeting to display a reminder.
Play Reminder Tone When Not in a Call	Specifies whether to play a sound along with the text reminder when the system is not in a call.
Show Information for Meetings Set to Private	Specifies whether to display details about meetings marked private.

Set Up the Distributed Media Service

By default, the RealPresence Immersive Studio system supports the Polycom RealPresence Distributed Media Application™ (DMA). RealPresence DMA enables multipoint conferences.

To set up the Distributed Media Service:

- 1 Go to the admin interface of RMX and configure DMA as the H323 gatekeeper and SIP server.
- 2 Login to the DMA web interface with a user account having Administrator privileges.
- 3 Configure MCU in DMA:
 - a In the DMA menu, go to **Network > MCU > MCUs** and press **Add** on the ACTIONS pane to add the details of the MCU (RMX) that you want to use for your conferencing needs.
 - b After filling in the details of the MCU (RMX), press **OK**. Make sure that the MCU state shows as "Connected to .. MCU" and "In service" as indicated by the status indicators in the first column of the table displayed in **Network > MCU > MCUs**.
- 4 Configure MCU pool:
 - a Go to **Network > MCU > MCU Pools** and press **Add** on the ACTIONS pane to add a MCU Pool. The Add MCU Pool window appears.
 - b Name the pool and select the MCU that was added previously in step 3 and move it to the Selected MCUs section. Press **OK**.
- 5 Configure MCU pool order:

- a Go to **Network > MCU > MCU Pool Orders** and press **Add** on the ACTIONS pane to add a MCU Pool order.
The Add MCU Pool Order window appears.
 - b Name the pool order and select the MCU pool that was added previously in step 4 and move it to the Selected MCU pools section. Press **OK**.
- 6 Configure the conference template:
- a Go to **Admin > Conference Manager > Conference Templates** and press **Add** on the ACTIONS pane to add a conference template.
The Add Conference Template window appears.
 - b Name the template and configure the rest of the settings as required. The resolution, video quality, line rate, etc that is applied to the conference depends on the configuration in the conference template.
- 7 Configure a DMA user:
- a In the menu, go to **User > Users** and press **Add** on the ACTIONS pane to add a user.
The Add User window appears.
 - b Configure the userid and password. You can also configure the class of service and bit rate. No special roles (Administrator/Auditor,Provisioner) are required for this DMA user.
- 8 Create a conference room:
- a Select the user that you created in step 7 and press **Manage conference rooms** on the ACTIONS pane.
The Conference Rooms window appears.
 - b Add a conference room by pressing **Add**.
The Add Conference Room window opens.
 - c Provide or generate a Room id (conference room number). Enable the conference template and select the conference template that was created in step 6.
 - d Enable MCU pool order and select the MCU pool order that was created in step 5.
- 9 Verify the above configuration:
- » Dial in to the conference room created above from the Immersive Studio or OTX Studio endpoint by dialing the dial-in number of the conference room. If this succeeds (codec should be able to enter the conference), then the configuration is correct.



Notes: Distributed Media Service

- These instructions do not cover all configuration items related to setting up a conference room in DMA. Refer to the DMA documentation for detailed instructions on setting up MCUs, pools, conference templates, etc.
- All the endpoints (conference initiator and conference participants) should be registered to DMA as H323 and/or SIP endpoints. This may not be required on the conference participants if you are using only an IP address to perform blast dialing.
- The DMA should have the RealPresence API license installed in it to use the meeting composer feature. This can be checked in **Admin > Local Cluster > Licenses > Active License**. If the Licensed capabilities field shows **RealPresence Platform API**, then the license is installed.
- There should be a MLA registered to the RMX for applying the proper layouts.

Configure the Distributed Media Service

To use the Meeting Composer functionality in RealPresence Immersive Studio or RealPresence OTX Studio, you must enable and configure Distributed Media Service.

To configure Distributed Media Service:

- 1 Login to the web UI of RealPresence Immersive Studio or RealPresence OTX Studio as admin.
- 2 Go to **Admin Settings > Servers > Distributed Media Service**.
- 3 Select the **Enable Multipoint Server** check box.
- 4 Configure the following settings:

Multipoint Server Settings

Setting	Description
Virtual Meeting Room (VMR) Number	Specifies the DMA conference room number/ID to use for conferencing activities, created in step 8.
Server Address	Specifies the DMA server that hosts the conference room/VMR.
Domain	Specifies the domain of the DMA user who owns the conference room. It should be the same as the domain displayed in the DMA admin web interface in User > Users in the room item for the user created in step 7.
User Name	Specifies the User ID of the DMA user, created in step 7, who owns the conference room. No special roles (Administrator/Auditor/Provisioner) are required for this DMA user. This user must own the VMR (conference room) entered in VMR Number. The user name value entered should be the same as the User ID displayed in the DMA admin web interface in User > Users for the user created in step 7.
Password	Specifies the password of the DMA user, created in step 7, who owns the DMA conference room.



Note: DMA username, domain, and password

The username, domain, and password in the Distributed Media Service page should match the User Id, Domain, and password shown in the **User > Users** section of the DMA admin web interface.

- 5 When you complete the Multipoint Server settings, press **Save** to save the details and perform validation of the values entered in the text boxes.

Configuration Status	Validation	Registration Status Field	Notes
Correct	Success	Online	
Incorrect	Failure	Offline	<p>An error message appears with the cause of the validation failure, for example:</p> <ul style="list-style-type: none"> • wrong username, password, or domain • insufficient resources in the configured RMX MCU

Immersive Settings

Immersive settings include the IP address of the secondary codecs in the RealPresence Immersive Studio setup. For information about configuring the Immersive settings, refer to [Configure the IP Addresses of the Component Codecs](#).

Room Control Devices

Control of the room features is built into the RealPresence Immersive Studio system, eliminating the need for an external control system.

To view the status, IP address, and port number used for room control devices:

- 1 Go to **Admin Settings > Room Control Devices**.
- 2 Select the device for which you want to see the settings.

The settings for each device are described below.

Room Device Settings

Setting	Description
Status	Specifies the state of the connection. The states are Connected , Not Connected , and Unknown .
IP Address	Specifies the IP address of the device that is being controlled.
Port Number	Specifies the port number for TCPIP connection of the device that is being controlled.

Configure the Diagnostic Settings

Polycom RealPresence Immersive Studio systems provide various screens that enable you to review information about calls made by the system, review network usage and performance, perform audio and video tests, and send system messages.

Polycom RealPresence Manageability Instrumentation Solution

The Polycom® RealPresence® Manageability Instrumentation solution simplifies management of Polycom RealPresence video collaboration services. RealPresence Manageability Instrumentation now enables you to collect, store, and export data in a consistent format across all Polycom endpoints, and hardware and software infrastructure systems. Polycom video and collaboration environments and infrastructure that include the Manageability Instrumentation solution capabilities are easier to monitor, operate, and secure.

RealPresence Manageability Instrumentation equips your Polycom devices with an embedded capability that enhances your ability to monitor them:

The Polycom Unified System logging Syslog transport format provides a system log message format compliant with RFC 5424 that enables you to log device events locally and remotely in a standardized way. Monitoring system logs is especially useful for troubleshooting and security purposes.

For detailed information on using the Manageability Instrumentation solution with your Polycom products, see the *Polycom RealPresence Manageability Instrumentation Solution Guide*.

Web Interface Diagnostics Screens

Read this section to learn how to find diagnostic information in the web interface.

To access the Diagnostics screens using the Polycom RealPresence Immersive Studio system web interface:

- 1 In your web browser address line, enter the RealPresence Immersive Studio or RealPresence OTX Studio system's IP address.
- 2 Enter the Admin ID as the user name (default is `admin`), and enter the Admin Remote Access Password, if one is set.
- 3 Click **Diagnostics** from any page in the web interface.

You can find some system information by clicking the **System** link in the blue bar at the top of the page.

The web interface's Diagnostics page has the following groups of settings in addition to the Send a Message application:

- System
- Audio and Video Tests

System Diagnostics

Diagnostic Screen	Description
Call Statistics	Displays information about the call in progress. To view more information about a specific stream, navigate to the desired stream and select More Info . From an individual stream view you can select Next Stream to view the next stream in the stream list.
System Status	Displays system status information.
Download Logs	Enables you to save system log information for each codec using separate web UI on each codec.
System Log Settings	<ul style="list-style-type: none"> • Specifies the Log Level to use. • Enables Remote Logging, H.323 Trace, and SIP Trace. • Specifies the Remote Log Server Address. • Allows you to Send Diagnostics and Usage Data to Polycom, and get information about the Polycom Improvement Program.
Restart System	Instructs the system to restart (system reboot). Restarting the RealPresence OTX Studio takes four minutes to complete. The system is not fully functional until the restart completes. During the restart the RealPresence Touch unpairs and repairs and the monitor lifts lower.
Sessions	View information about everyone logged in to the RealPresence Immersive Studio system.

System Information

You can find system information by clicking the **System** link in the blue bar at the top of the page.

Call Statistics

To display call statistics (in a call):

- » Go to **Diagnostics > System > Call Statistics**.

Displays information about the call in progress. Streams associated with the participant are displayed beneath the participant information in the order center, left, and right. If the system is not in a call, the page displays **The System is not currently in a call**.

Select **More Info** to display the following detailed information:

Participant information

- Participant Name
- Participant Number
- Participant System
- Call Type
- Call Speed

- Encryption

Participant Streams

- Stream ID; possible stream IDs include Audio TX, Audio RX, Video TX, Video RX, Content TX, and Content RX
- Stream quality indicator; possible colors are green, yellow, and red.
- Protocol
- Format
- Rate Used
- Frame Rate
- Packets Lost
- % Packet Loss
- Jitter
- Encryption type, key exchange algorithm type, and key exchange check code (if the encryption option is enabled and the call is encrypted)
- Error concealment type, such as lost packet recovery (LPR), retransmission, or dynamic bandwidth allocation (DBA)

System Status

To display system status:

- » Go to **Diagnostics > System > System Status**.

Displays the following system status information. When the status information for three systems is shown, the order is primary system, left system, and right system.

- Auto-Answer Point-to-Point Video
- Remote Control
- Audio Devices
- VisualBoard
- Global Directory Server
- Presence Service
- IP Network
- Gatekeeper
- SIP Registrar Server
- Log Threshold
- Meeting Password
- Calendaring Service
- Distributed Media Service
- People Display
- Content Display
- Display Switcher

- Lighting Controller
- SoundStructure
- VisualBoard Display

Select **More Info** beside each topic for additional detail and links to configuration screens.

Download Logs

To download logs:

- 1 Go to **Diagnostics > System > Download Logs**.
- 2 Select **Download system log**, and then specify a location on your computer to save the file.

System Log Settings

The system log captures devices and server events in a consistent manner within a log. The log can assist you when troubleshooting system issues. Log settings apply to all three systems in your RealPresence Immersive Studio setup.

To configure system log settings:

- 1 In your web browser address line, enter the RealPresence Immersive Studio system's IP address.
- 2 Enter the Admin ID as the user name (default is `admin`), and enter the Admin Remote Access Password, if one is set.
- 3 Go to **Diagnostics > System > System Log Settings**.
- 4 Configure these settings.

System Log Settings

Setting	Description
Log Level	Sets the minimum log level of messages stored in the Polycom RealPresence Immersive Studio system's flash memory. DEBUG logs all messages. WARNING logs the fewest number of messages. Polycom recommends leaving this setting at the default value of DEBUG.
Enable Remote Logging	Specifies whether remote logging is enabled. Enabling this setting causes the Polycom RealPresence Immersive Studio system to send each log message to the specified server in addition to logging it locally. The system immediately begins forwarding its log messages when you select Save . Encryption is not supported for remote logging, so Polycom recommends remote logging only for secure, local networks.
Remote Log Server Address	Specifies the server address and port.
Remote Log Server Transport Protocol	Specifies the type of transport protocol: <ul style="list-style-type: none"> • UDP • TCP • TLS (secure connection)

System Log Settings

Setting	Description
Enable H.323 Trace	Logs additional H.323 connectivity information.
Enable SIP Trace	Logs additional SIP connectivity information.
Send Diagnostics and Usage Data to Polycom	Sends crash log server information to Polycom to help us analyze and improve the product. Click the Polycom Improvement Program button to view information about how your data is used.



Caution: Do not enable the following settings unless advised to do so by Polycom Support:

- Enable H.323 Trace
- Enable SIP Trace
- Send Diagnostics and Usage Data to Polycom

5 Select **Download system log**, and then specify a location on your computer to save the file.

Restart System**To restart the system:**

» In the primary codec web UI, go to **Diagnostics > System > Restart System**.

Sessions

You can use the sessions list to see information about everyone logged in to a RealPresence Immersive Studio system including:

- Type of connection, for example, Web
- User ID associated with the session, typically Admin or User
- Remote IP address, the addresses of people logged in to the system from their computers

To view the Sessions List:

» Go to **Diagnostics > System > Sessions**.

Audio and Video Tests**Audio Meters**

Audio meters measure the strength of audio signals from content audio and recording outputs (HDMI1, HDMI2, HDMI3, component, and Recording Out).

The Audio Meters indicate peak signal levels. Set signal levels so that you see peaks between +3dB and +7dB with normal speech and program material. Occasional peaks of +12dB to +16dB with loud transient noises are considered acceptable. A meter reading of +20dB corresponds to 0dBFS in the RealPresence Immersive Studio system audio. A signal at this level is likely clipping the audio system.

Meters function only when the associated input is enabled. Currently, the microphone meters function is only available from the SoundStructure Studio software.

To use audio meters:

- » Go to **Diagnostics > Audio and Video Tests > Audio Meter**.

Calibrate the Microphone

Microphone calibration is required before making TIP calls.

To calibrate the microphones:

- 1 In the primary codec web user interface, go to **Diagnostics > Audio and Video Tests > Microphone Calibration**.

The Microphone Calibration screen displays. The screen displays a representation of the furniture in the room with circles representing the seating locations.

- 2 Sit in any of the seats at the table. It may be convenient to start at the far right or left seat and work your way around the table(s).
- 3 On the **Microphone Calibration** screen, select the circle corresponding to your current seated location. A message box showing progress appears.
- 4 Face the monitors and speak normally. After a few seconds, a successful calibration message appears.

If calibration fails, a calibration failure message appears. Close the message and try again. If you are unable to achieve a successful calibration, verify proper microphone installation and try again. Contact Polycom Support to verify proper installation, if necessary.

- 5 Close the message box.
- 6 Repeat steps 2 through 5 for all seating locations.



Note: Keep track of the calibrated seats.

The Microphone Calibration Screen does not provide any indication of whether the calibration process has been performed for any given seat. Carefully track the seats as you perform the calibration so no seat is omitted.

Configure the Utilities Settings

In the web interface, you can configure, manage, and monitor Polycom RealPresence Immersive Studio systems from a computer. You can also use Polycom RealPresence Resource Manager, SNMP, or the API commands.

Manage System Profiles

Administrators managing systems that support multiple applications can change system settings using profiles. You can store a RealPresence Immersive Studio system profile on a computer as a .profile file. The number of profiles you can save is unlimited.

The following settings are included in a profile:

- Home screen settings
- User access levels
- Icon selections
- Option keys
- System behaviors

Passwords are not included when you store a profile.



Note: Use profiles only to back up system settings.

Polycom recommends using profiles only as a way to back up system settings. Attempting to edit a stored profile or upload it to more than one system on the network can result in instability or unexpected results.

Store a Profile

You can download and store a profile from the Profile Center.

To store a profile:

- 1 Go to **Utilities > Services > Profile Center**.
- 2 Select **Download**.
- 3 Save the file to a location on your computer.

Upload a Profile

You can upload a Settings Profile from your system to the Profile Center.

To upload a profile:

- 1 Reset the Polycom RealPresence Immersive Studio system to restore default settings.
- 2 Go to **Utilities > Services > Profile Center**.
- 3 Next to **Upload Settings Profile**, select **Browse**, and navigate to the location of the profile .csv file on your computer.
- 4 Select **Open** to upload the .csv file to your system.

Call Detail Report (CDR)

The Call Detail Report (CDR) provides the system's call history. Within 5 minutes after ending a call, the CDR is written to memory; you can then download the data in CSV format for sorting and formatting.

Every call is added to the CDR whether it is placed or received. If a call does not connect, the report shows the reason. In multipoint calls, each far site is shown as a separate call, but all have the same conference number.

Polycom recommends that you download the report periodically to prevent its growing to an unmanageable size. If you consider that 150 calls result in a CDR of approximately 50 KB, you might set up a schedule to download and save the CDR after about every 1000–2000 calls just to keep the file easy to download and view. Remember that your connection speed also affects how fast the CDR downloads.

Enable CDR

In order to use the CDR, you must first enable it.

To enable CDR:

- » Go to **Admin Settings > General Settings > System Settings > Recent Calls** and enable the **Call Detail Report** check box.

View and Download the CDR

You can open or save the CDR file on your computer.

To view and download the CDR:

- 1 Go to **Utilities > Services > Call Detail Report (CDR)**.
- 2 Select **Most Recent Call Report**.
A report for each system and an aggregated report are delivered in a compressed file.
- 3 Specify whether to open or save the file on your computer.

Information in the Call Detail Report (CDR)

The following table describes the data fields in the Call Detail Reports.

Call Detail Report Information

Data	Description for Individual System Report	Description for Aggregated Report
Row ID	Each call is logged on the first available row. A call is a connection to a single site, so there might be more than one call in a conference.	Same as primary system.
Start Date	The call start date, in the format dd-mm-yyyy.	Same as primary system.
Start Time	The call start time, in the 24-hour format hh:mm:ss.	Same as primary system.
End Date	The call end date.	Same as primary system.
End Time	The call end time.	Same as primary system.
Call Duration	The length of the call.	Same as primary system.
Account Number	If Require Account Number to Dial is enabled on the system, the value entered by the user is displayed in this field.	Same as primary system.
Remote System Name	The system name of the far site.	Same as primary system.
Call Number 1	Outgoing calls: The number dialed from the first call field, not necessarily the transport address. Incoming calls: The caller ID information from the first number received from a far site.	Combined addresses separated by a semicolon.
Call Number 2 (If applicable for call)	Outgoing calls: The number dialed from the second call field, not necessarily the transport address. Incoming calls: The caller ID information from the second number received from a far site.	Same as primary system.
Transport Type	The type of call, either H.323 (IP) or SIP.	Same as primary system.
Call Rate	The bandwidth negotiated with the far site.	Sum of the call rates of the individual calls.
System Manufacturer	The name of the system manufacturer, model, and software version, if they can be determined.	Same as primary system.
Call Direction	In for calls received. Out for calls placed from the RealPresence Immersive Studio system.	Same as primary system.
Conference ID	A identification number given to each conference. A conference can include more than one far site, so there might be more than one row with the same conference ID.	Same as primary system. Shown as 0 (zero) in this release.
Call ID	Identifies individual calls within the same conference.	Same as primary system.
Total H.320 Channels Used	0 (zero) indicates that the call did not connect. 1 indicates a connected call.	The total number of codecs used in the call.

Call Detail Report Information

Data	Description for Individual System Report	Description for Aggregated Report
Endpoint Alias	The alias of the far site.	Same as primary system.
Endpoint Additional Alias	An additional alias of the far site.	Same as primary system.
View Name	Names the web or local interface used in the call.	Same as primary system.
User ID	Lists the ID of the user who placed the call.	Same as primary system.
Endpoint Transport Address	The actual address of the far site, not necessarily the address dialed.	Same as primary system.
Audio Protocol (Tx)	The audio protocol transmitted to the far site, such as G.728 or G.722.1.	Same as primary system.
Audio Protocol (Rx)	The audio protocol received from the far site, such as G.728 or G.722.	Same as primary system.
Video Protocol (Tx)	The video protocol transmitted to the far site, such as H.263 or H.264.	Same as primary system.
Video Protocol (Rx)	The video protocol received from the far site, such as H.261 or H.263.	Same as primary system.
Video Format (Tx)	The video format transmitted to the far site, such as CIF or SIF.	Same as primary system.
Video Format (Rx)	The video format received from the far site, such as CIF or SIF.	Same as primary system.
Disconnect Local ID and Disconnect Reason	The identity of the user who initiated the call and the reason the call was disconnected.	Same as primary system.
Q.850 Cause Code	The standard Q.850 cause code showing how the call ended.	Same as primary system.
Total H.320 Errors	The number of H.320 errors experienced during the call.	Same as primary system. This value should be 0 (zero).
Average Percent of Packet Loss (Tx)	The combined average of the percentage of both audio and video packets transmitted that were lost during the five seconds preceding the moment at which a sample was taken. This value does not report a cumulative average for the entire H.323 call.	Average of the individual call numbers.
Average Percent of Packet Loss (Rx)	The combined average of the percentage of both audio and video packets received that were lost during the five seconds preceding the moment at which a sample was taken. This value does not report a cumulative average for the entire H.323 call.	Average of the individual call numbers.
Average Packets Lost (Tx)	The number of packets transmitted that were lost during an H.323 call.	Sum of packets that were lost in the individual calls.

Call Detail Report Information

Data	Description for Individual System Report	Description for Aggregated Report
Average Packets Lost (Rx)	The number of packets from the far site that were lost during an H.323 call.	Sum of packets that were lost in the individual calls.
Average Latency (Tx)	The average latency of packets transmitted during an H.323 call based on round-trip delay, calculated from sample tests done once per minute.	Average of the individual call numbers.
Average Latency (Rx)	The average latency of packets received during an H.323 call based on round-trip delay, calculated from sample tests done once per minute.	Average of the individual call numbers.
Maximum Latency (Tx)	The maximum latency for packets transmitted during an H.323 call based on round-trip delay, calculated from sample tests done once per minute.	Maximum of the individual call numbers.
Maximum Latency (Rx)	The maximum latency for packets received during an H.323 call based on round-trip delay, calculated from sample tests done once per minute.	Maximum of the individual call numbers.
Average Jitter (Tx)	The average jitter of packets transmitted during an H.323 call, calculated from sample tests done once per minute.	Average of the individual call numbers.
Average Jitter (Rx)	The average jitter of packets received during an H.323 call, calculated from sample tests done once per minute.	Average of the individual call numbers.
Maximum Jitter (Tx)	The maximum jitter of packets transmitted during an H.323 call, calculated from sample tests done once per minute.	Maximum of the individual call numbers.
Maximum Jitter (Rx)	The maximum jitter of packets received during an H.323 call, calculated from sample tests done once per minute.	Maximum of the individual call numbers.
Call Priority	This function is not supported in RealPresence Immersive Studio or RealPresence OTX Studio.	

Send a Message

If you are experiencing difficulties with connectivity or audio, you can send a message to the system that you are managing. Only the near site can see the message; it is not broadcast to all the sites in the call.

To send a near-site message:

- 1 Go to **Utilities > Send a Message**.
- 2 In the **Send a Message** field, enter the text. You can enter up to 100 characters.
- 3 Select **Send**.

The message is displayed for 15 seconds on the screen of the system that you are managing.

Monitor a Room or Call

The remote monitoring feature enables administrators to view the room where the system is installed. Camera controls and presets are not supported in this release of RealPresence Immersive Studio.

To monitor a room or a call using the web interface:

- » Go to **Utilities > Tools > Remote Monitoring**.

Display a Closed Caption

The closed caption feature is not supported in this release of the RealPresence Immersive Studio system.

Security Profile Definitions

Configure the Low Security Profile

The Low Security Profile is supported in this release of the RealPresence Immersive Studio. The following table shows the default values for specific Admin settings.

Low Security Profile Settings

Admin Settings Area	Low		
	Range	Default Value	Configurable
General Settings			
System Settings			
Auto Answer Point to Point Video	Checkbox	Disabled	Yes
Auto Answer Multipoint Video	Checkbox	Disabled	Yes
Call Detail Report	Checkbox	Enabled	Yes
Enable Recent Calls	Checkbox	Enabled	Yes
Pairing			
SmartPairing Mode	Disabled Automatic Manual	Disabled	Yes
Network			
IP Network			
Enable SIP	Checkbox	Enabled	Yes
Transport Protocol	Auto TLS TCP UDP	Auto	Yes
Dialing Preference			
Scalable Video Coding Preference (H.264)	AVC Only	AVC Only	Yes

Low Security Profile Settings

Admin Settings Area	Low		
	Range	Default Value	Configurable
Security			
Global Security			
Security Profile			
Security Profile	Maximum High Medium Low	Low	Yes
Authentication			
Active Directory Authentication	Checkbox	Disabled	Yes
Access			
Enable Network Intrusion Detection System (NIDS)	Checkbox	Disabled	Yes
Enable Web Access	Checkbox	Enabled	Yes
Restrict to HTTPS Note: If Restrict to HTTPS is enabled, the SNMP Listening Port must be set to 443.	Checkbox	Disabled	Yes
Web access port (http) Note: You cannot select this setting if the Restrict to HTTPS setting is enabled.	16-bit integer	80	Yes
Enable Remote Access: Telnet	Checkbox	Disabled	Yes
Enable Remote Access: SNMP	Checkbox	Disabled	Yes
Lock Port after Failed Logins	Off,2-10	Off	Yes
Port Lock Duration	1,2,3,5,10,20,30 minutes, 1,2,4,8 hours	1 minute	Yes
Reset Port Lock Counter After	Off,[1..24] hours	Off	Yes
Enable Whitelist	Checkbox	Disabled	Yes
Idle Session Timeout	1,2,3,5,10,20,30,45 minutes, 1,2,4,8 hours	10	Yes
Maximum Number of Active Sessions	10-50	25	Yes
Allow Video Display on Web	Checkbox	Disabled	Yes

Low Security Profile Settings

Admin Settings Area	Low		
	Range	Default Value	Configurable
Encryption			
Require AES Encryption for Calls	Off When Available Required-Video Calls Required-All Calls	Off	Yes
Require FIPS 140 Cryptography	Checkbox	Disabled	Yes
Local Accounts			
Account Lockout			
Lock Admin Account After Failed Logins	Off,2-10	Off	Yes
Admin Account Lock Duration	1,2,3,5 minutes	1	Yes
Reset Admin Account Lock Counter After	Off,[1..24] hours	Off	Yes
Lock User Account After Failed Logins	Off,2-10	Off	Yes
User Account Lock Duration	1,2,3,5,10,20,30 minutes, 1,2,4,8 hours	1 minute	Yes
Reset User Account Lock Counter After	Off,[1..24] hours	Off	Yes
Login Credentials			
Use Room Password for Remote Access	Checkbox	Enabled	Yes
Require User Login for System Access	Checkbox	Disabled	Yes
Password Requirements			
Admin (Room, Remote), User (Room, Remote)			
Reject Previous Passwords	Off,1-16	Off	Yes
Minimum Password Age in Days	Off,1,5,10,15,20,30	Off	Yes
Maximum Password Age in Days	Off,30,60,90,100,110 , 120,130,140,150,160 ,170,180	Off	Yes
Minimum Changed Characters	Off,1-4,All	Off	Yes
Password Expiration Warning	Off,1-7	Off	Yes
Remote Access (Admin Remote, User Remote)			
Minimum Length	Off,1-16,32	Off	Yes

Low Security Profile Settings

Admin Settings Area	Low		
	Range	Default Value	Configurable
Require Lowercase	Off, 1,2,All	Off	Yes
Require Uppercase	Off, 1,2,All	Off	Yes
Require Numbers	Off, 1,2,All	Off	Yes
Require Special Characters	Off, 1,2,All	Off	Yes
Maximum Consecutive Repeated Characters	Off, 1-4	Off	Yes
Can contain ID or Its Reverse Form	Checkbox	Enabled	Yes
User (Room), Admin (Room)			
Minimum Length	Off, 1-16,32	Off	Yes
Require Lowercase	Off, 1,2,All	Off	Yes
Require Uppercase	Off, 1,2,All	Off	Yes
Require Numbers	Off, 1,2,All	Off	Yes
Require Special Characters	Off, 1,2,All	Off	Yes
Maximum Consecutive Repeated Characters	Off, 1-4	Off	Yes
Can contain ID or Its Reverse Form	Checkbox	Enabled	Yes
Meeting			
Minimum Length	Off, 1-20,32	Off	Yes
Require Lowercase	Off, 1,2,All	Off	Yes
Require Uppercase	Off, 1,2,All	Off	Yes
Require Numbers	Off, 1,2,All	Off	Yes
Require Special Characters	Off, 1,2,All	Off	Yes
Reject Previous Passwords	Off, 1-16	Off	Yes
Minimum Password Age in Days	Off, 1,5,10,15,20,30	Off	Yes
Maximum Consecutive Repeated Characters	Off, 1-4	Off	Yes
SNMP			
Note: SNMP passwords are applicable only when the system uses SNMP v3.			
Minimum Length	1-16,32	1	Yes
Require Lowercase	Off, 1,2,All	Off	Yes
Require Uppercase	Off, 1,2,All	Off	Yes

Low Security Profile Settings

Admin Settings Area	Low		
	Range	Default Value	Configurable
Require Numbers	Off, 1,2,All	Off	Yes
Require Special Characters	Off, 1,2,All	Off	Yes
Reject Previous Passwords	Off, 1-16	Off	Yes
Minimum Password Age in Days	Off, 1,5,10,15,20,30	Off	Yes
Maximum Consecutive Repeated Characters	Off, 1-4	Off	Yes
Can contain ID or Its Reverse Form	Checkbox	Disabled	Yes
Security Banner			
Enable Security Banner	Checkbox	Disabled	Yes
Banner Text	DoD Custom	Custom	Yes
Local System Banner Text	Unicode characters, 2048 bytes max	Null (no text)	Yes
Remote System Banner Text	Unicode characters, 2048 bytes max	Null (no text)	Yes
Certificates			
Certificate Options			
Certificate Validation (Web Server)	Checkbox	Disabled	Yes
Certificate Validation (Client Apps)	Checkbox	Disabled	Yes
Revocation			
Revocation Method	OCSP CRL	OCSP	Yes
Allow Incomplete Revocation Checks	Checkbox	Enabled	Yes
Servers			
Directory Servers			
XMPP	Provisioned-only	Disabled	Yes (via provisioning)
Service Type	Off Microsoft Polycom GDS LDAP	Off	Yes
Note: the <i>Microsoft</i> selection means Microsoft Lync Server 2010 or 2013, depending on what is installed.			

Low Security Profile Settings

Admin Settings Area	Low		
	Range	Default Value	Configurable
SNMP			
Version1	Checkbox	Disabled	Yes
Version2c	Checkbox	Disabled	Yes
Version3	Checkbox	Enabled	Yes
Calendaring Service			
Enable Calendaring Service	Checkbox	Disabled	Yes

Configure Polycom RealPresence Touch

Perform the RealPresence Touch Out-of-Box Setup

You can perform the RealPresence Touch out-of-box setup by ensuring that the RealPresence Touch is connected and navigating through three simple screens.

To perform the RealPresence Touch out-of-box setup:

- 1 If the RealPresence Touch is not connected, connect it to the Ethernet cable specified for use by Polycom. If this is the first time the device has been powered on, the language screen will display automatically.
- 2 On the language screen, touch the language you want to use and touch **Next**.
- 3 On the password screen the administrator password is automatically set to your system serial number. Polycom recommends that you create a new, custom administrator password. To create a new administrator password, touch **Create New Password**. In the **Password** field, type in your new password. In the **Confirm Password** field type in your new password again. Touch **Save**.
- 4 On the Network Settings screen type in the network parameters. For information about obtaining network parameters refer to [Obtain the Network Parameters](#).
- 5 The RealPresence Touch pairing screen automatically displays.

Pair RealPresence Touch with RealPresence Immersive Studio or RealPresence OTX Studio.

You can easily pair your RealPresence Touch with RealPresence Immersive Studio or RealPresence OTX Studio room systems.

To pair the RealPresence Touch:

- 1 Touch **Manually Pair**.
- 2 In the **Device Address** field, enter the IP address.
- 3 In the **Admin ID** field, enter the administrator user name.
- 4 In the **Password** field, enter the administrator password.
- 5 Touch **Pair**.
- 6 You may be prompted that an update is available. Touch **Update** and the update begins. After a few minutes, the Home screen appears.

Customize the RealPresence Touch Home Screen

You can use the RealPresence Group 700 system web interface to configure how information is displayed on the Home screen of the RealPresence Touch device. These settings are included in the RealPresence Group System settings profile, and included in bundled provisioning when using RealPresence Resource Manager. For more information about RealPresence Group systems settings refer to the Polycom RealPresence Group Series Administrator Guide available at support.polycom.com.

To configure the RealPresence Touch Home Screen using the web interface:

- 1 In the web interface, go to **Admin Settings > General Settings > Pairing > RealPresence Touch Home Screen Configuration**.
- 2 Configure the settings on the Home Screen Settings page that are described in the following sections.

Choose Icon Buttons That Display on the RealPresence Touch Home Screen

By default, two icon buttons appear in the lower center of the Home screen; users see the **Place a Call** and **Show Content** icons. However, you can customize the number of screens and Home screen icons in a preferred order. Once you customize the Home screen configuration, users can scroll through one to three Home Screens, with up to three icons on each screen.

To display the Home screen icons:

- 1 In the web user interface, go to **Admin Settings > General Settings > Pairing > RealPresence Touch Home Screen Configuration**.
- 2 Under **Configure Home Screen**, click **Configure Home Screen Options**.
- 3 At **Home screen 1 > Button 1**, select one to three icon buttons to appear per screen in your preferred order. You can select from the following icon buttons:
 - None (no icon)
 - Place a Call
 - Show Content
 - Keypad
 - Contacts
 - System Information
 - User Settings
 - Administration
- 4 If you want to include more than one Home screen, continue selecting icon buttons for **Home Screen 2** and **Home Screen 3** until all screens are configured. For example, Home Screen 1 > Button 1 > Recent Call Button 2 > Place a Call > Button 3 > Contacts.
- 5 To save your selections, click **Save**.
Your new selections display on the RealPresence Touch Home screens.

Customize the Place a Call Screen Icon Buttons on the RealPresence Touch Device

You can customize the Place a Call screen to display certain icon buttons. Since there two ways to place a call by default, after you tap the Place a Call button, both options display on the screen. You can customize one of the icon buttons to be the default. The other Place a Call icon button continues to display at the top of the screen.

To customize the Place A Call screen icon buttons:

- 1 In the web interface, go to **Admin Settings > General Settings > Pairing > RealPresence Touch Home Screen Configuration**.
- 2 Under **Configure Home Screen**, click **Place A Call Screen**.
- 3 Under **Select Preferred Sub Menu**, choose from the following:
 - Keypad
 - Contacts
- 4 Click **Save**.

Your new selection displays on the RealPresence Touch Home screens.

Change the Background Image of the Home Screen on the RealPresence Touch Device

The RealPresence Touch Home screen displays a blank wallpaper, however, three optional wallpaper images are available from the web interface.

To change the background image:

- 1 In the web interface, go to **Admin Settings > General Settings > Home Screen Settings > Wall Paper**.
- 2 Select the image that you want to use.

The selected image is displayed on the main monitor and on the RealPresence Touch.